

Marlin 1895 45 70 Govt Loading Gate - Marlin 1895 45-70 Load Gate (gold)

[Rifle Parts](#) > [Bolt Parts](#) > [Breech Bolts & Blocks](#)

The RPP Flyweight Loading Gate makes reloading your Marlin 1894 or 1854 rifle significantly easier. It is precisely machined from high-quality 7075-T6 aluminum and hard-anodized for extreme durability.

Features:

Compatibility: Fits Marlin 1894 and 1854 chambered in .357 Mag, .44 Mag, and .45 Colt

Lightweight Operation: Spring tension reduced by up to 70% - requires only 1.5 lbs of opening force

Optimized Cartridge Feeding: Improved clearance and smooth, reliable feeding

Quick Installation: Simple 10-15 minute drop-in install

Color: Gold

NO IMAGE
AVAILABLE

Attributes

- Name: [Marlin 1895 45-70 Load Gate \(gold\)](#)
- Manufacturer: [RANGER POINT](#)
- Product no.: EU2014787
- Mfr. No.: 21
- Weapon type: Marlin
- Delivery weight: 0.23kg
- Shipping height: 25.4mm
- Shipping width: 152.4mm
- Shipping length: 203.2mm
- UPC: 850078124173

Table of Contents

- Startpage
- Marlin 1895 4570 Load Gate Safety Instruction Guide
- About Us

Marlin 1895 4570 Load Gate Safety Instruction Guide

Introduction

Thank you for choosing the Marlin 1895 4570 Load Gate. This product is designed to enhance the reloading experience of your Marlin 1894 or 1854 rifle. To ensure safe and effective use, please read this safety instruction guide carefully. It contains important safety information, usage instructions, and disposal guidelines.

General Safety Guidelines

- Always handle firearms with care and assume they are loaded until verified otherwise.
- Store the Marlin 1895 4570 Load Gate in a secure location out of reach of children and unauthorized users.
- Regularly inspect the loading gate for signs of wear or damage.
- Only use the loading gate with compatible Marlin rifles (1894 and 1854 models).
- Be aware of your surroundings when reloading and ensure that no one is in close proximity.

Specific Safety Precautions for Use

- Ensure the firearm is pointed in a safe direction during loading and unloading.
- Use only the specified ammunition types: .357 Mag, .44 Mag, and .45 Colt.
- Do not attempt to modify the loading gate or the firearm in any way.
- If you experience any difficulties during reloading, stop and consult a qualified gunsmith.
- Always wear appropriate eye and ear protection when handling firearms.

Instructions for Installation and Usage

Installation

1. **Preparation:** Ensure the firearm is unloaded and pointed in a safe direction.
2. **Remove the Old Loading Gate:** If applicable, carefully remove the existing loading gate from the rifle.
3. **Install the New Loading Gate:**
 - Align the new loading gate with the designated slot on the rifle.
 - Gently press the gate into place until it is securely fitted.
4. **Check Functionality:** Test the loading gate by cycling through the reloading process to ensure it operates smoothly.

Usage

- To reload:
 1. Open the loading gate by applying a light force.
 2. Insert the cartridges into the magazine tube.
 3. Close the loading gate securely.
- Ensure that the loading gate operates smoothly and does not jam.

Disposal Instructions

- When disposing of the Marlin 1895 4570 Load Gate, follow local regulations regarding the disposal of metal products.
- If the loading gate is damaged or no longer functional, consider recycling the aluminum material where possible.

Contact Information for Further Support

For questions or concerns regarding the Marlin 1895 4570 Load Gate, please contact the manufacturer or visit their official website for assistance.

Conclusion

By following these safety instructions, you can ensure a safe and enjoyable experience with your Marlin 1895 4570 Load Gate. Always prioritize safety and proper handling practices when using firearms. Thank you for choosing our product.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk