

OBI Camera Lock Locking RIGHT BLK

[Shooting Accessories](#) > [Duty Gear](#)

The Camera Lock mounts securely using a standard 1/4-20 bolt, making it an ideal choice for cameras, spotting scopes, and binoculars. It can even be mounted to the wall to help you keep your gear organized and ready to go.

Built with integrated Arca compatibility, the Camera Lock easily clamps into your tripod, allowing you to hang it from your backpack strap or tripod leg for quick access on the move. Despite its compact size, it offers incredible versatility and durability for any setup.

Each unit comes with a small adjustable tension locking lever that lets you fasten the post securely in place. To suit your preferred setup, the Camera Lock is available in both right-hand and left-hand configurations, making it effortless to reach and operate the lever regardless of your mounting position.

Note: You will need at least one Clamp Lock or Slide Lock, and one RP M, QD P, or Anywhere Mount to complete your setup.

NO IMAGE
AVAILABLE

Attributes

- Name: [OBI Camera Lock Locking RIGHT BLK](#)
- Manufacturer: [OBI SYSTEMS](#)
- Product no.: EU2015550
- Mfr. No.: OBi01007-BLK
- Colour: Black
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 767637841047

Table of Contents

- Startpage
- OBI Camera Lock Safety Instructions
- About Us

OBI Camera Lock Safety Instructions

Introduction

Thank you for choosing the OBI Camera Lock. This product is designed to securely mount your cameras, spotting scopes, and binoculars, ensuring ease of access and organization. To ensure safe and effective use of the OBI Camera Lock, please read and follow these safety instructions carefully.

General Safety Guidelines

- **Product Safety:** Always ensure the product is used according to the guidelines provided. This product is intended for nonfood use only.
- **Enhanced Recalls:** In the event of a product recall, you will be notified through standardized recall notices. Please check for updates regularly.
- **Online Shopping:** If purchased online, ensure that the seller complies with EU safety requirements.
- **Special Consumer Focus:** This product is not intended for use by children without adult supervision. Keep out of reach of children.
- **EU Contact Point:** For any safety inquiries, please refer to the contact information provided with your product packaging.
- **Rapid Alerts:** Stay informed about product safety updates through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Mounting Stability:** Ensure that the Camera Lock is securely mounted before use. Check that all components are tightened and stable.
- **Weight Limit:** Do not exceed the weight limit specified for the Camera Lock. Overloading may cause damage or failure.
- **Avoid Sharp Objects:** Keep sharp objects away from the Camera Lock to prevent damage.
- **Inspect Regularly:** Regularly inspect the Camera Lock for any signs of wear or damage. Do not use if damaged.
- **Proper Handling:** Handle the Camera Lock with care to avoid dropping or mishandling, which could lead to injury or damage.

Instructions for Installation and Usage

1. Installation:

- Use a standard 1/420 bolt to mount the Camera Lock securely.
- Ensure that the mount is attached to a stable surface or tripod.
- If mounting to a wall, ensure the wall material can support the weight of the Camera Lock and attached equipment.

2. Usage:

- Adjust the tension locking lever to secure the post in place.
- For righthand or lefthand configurations, choose the appropriate setup that allows easy access to the lever.
- When not in use, store the Camera Lock in a safe location to prevent damage.

Disposal Instructions

- **Environmental Considerations:** Dispose of the Camera Lock responsibly. Follow local regulations for electronic waste disposal.
- **Recycling:** If possible, recycle the product materials to minimize environmental impact.

Contact Information for Further Support

For any questions or concerns regarding the OBI Camera Lock, please refer to the contact information provided with your product packaging.

Thank you for your attention to these important safety instructions. Enjoy using your OBI Camera Lock!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk