

OBI Camera Lock Locking LEFT BLK

[Shooting Accessories](#) > [Duty Gear](#)

The Camera Lock mounts securely using a standard 1/4-20 bolt, making it an ideal choice for cameras, spotting scopes, and binoculars. It can even be mounted to the wall to help you keep your gear organized and ready to go.

Built with integrated Arca compatibility, the Camera Lock easily clamps into your tripod, allowing you to hang it from your backpack strap or tripod leg for quick access on the move. Despite its compact size, it offers incredible versatility and durability for any setup.

Each unit comes with a small adjustable tension locking lever that lets you fasten the post securely in place. To suit your preferred setup, the Camera Lock is available in both right-hand and left-hand configurations, making it effortless to reach and operate the lever regardless of your mounting position.

Note: You will need at least one Clamp Lock or Slide Lock, and one RP M, QD P, or Anywhere Mount to complete your setup.

NO IMAGE
AVAILABLE

Attributes

- Name: [OBI Camera Lock Locking LEFT BLK](#)
- Manufacturer: [OBI SYSTEMS](#)
- Product no.: EU2015552
- Mfr. No.: OBi01008-BLK
- Colour: Black
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- UPC: 767637841061

Table of Contents

- Startpage
- OBI Camera Lock Safety Instructions
- About Us

OBI Camera Lock Safety Instructions

Introduction

Thank you for choosing the OBI Camera Lock. This guide provides important safety instructions and usage guidelines to ensure the safe and effective use of your Camera Lock. Please read this manual carefully before installation and use.

General Safety Guidelines

- Always ensure that the Camera Lock is securely fastened before use.
- Inspect the Camera Lock regularly for any signs of wear or damage.
- Do not exceed the weight limit specified for the Camera Lock.
- Keep the Camera Lock out of reach of children and vulnerable individuals when not in use.
- Use the Camera Lock only for its intended purpose, as specified in this manual.
- In case of any malfunction or damage, discontinue use immediately and contact support.

Specific Safety Precautions for Use

- Ensure that the mounting surface is stable and can support the weight of the Camera Lock and any attached equipment.
- When mounting to a wall, use appropriate anchors and screws suitable for the wall type.
- Avoid using the Camera Lock in extreme weather conditions that may affect its performance.
- Do not attempt to modify or disassemble the Camera Lock.
- Always use the adjustable tension locking lever to secure the post in place before use.

Instructions for Installation and Usage

Installation

1. Gather Required Tools:

- Standard 1/420 bolt (included)
- Appropriate anchors and screws if mounting to a wall

2. Mounting the Camera Lock:

- For tripod use:
 - Attach the Camera Lock to your tripod by securing the 1/420 bolt through the mounting hole.
- For wall mounting:
 - Mark the desired location on the wall.
 - Drill holes and insert anchors as necessary.
 - Secure the Camera Lock using screws.

3. Adjusting the Tension:

- Use the adjustable tension locking lever to set the desired tension for your equipment.

Usage

• Attaching Equipment:

- Clamp your camera, spotting scope, or binoculars securely into the Camera Lock.

• Accessing Equipment:

- For quick access, hang the Camera Lock from your backpack strap or tripod leg.

- **Operating the Lever:**
 - Ensure that the lever is easily reachable for quick adjustments.

Disposal Instructions

- Dispose of the Camera Lock in accordance with local regulations.
- If the Camera Lock is no longer functional, consider recycling the materials if possible.
- Do not dispose of the Camera Lock in regular household waste.

Contact Information for Further Support

For any safety inquiries or support needs, please contact the manufacturer directly through the provided channels. Ensure you have your product details ready for assistance.

Thank you for following these safety instructions. Enjoy using your OBI Camera Lock responsibly and safely!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk