

Lever Action Triggers (Pull weight is not adjustable) - Marlin Lever Action Trigger for Model 336, 1894, and 1895 - 3-3.5lb Pull - Black - Straight

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

Whether you compete in cowboy action shooting, enjoy casual range time, or head into the field as a dedicated hunter, one principle always holds true: a rifle can only be as good as its trigger. For shooters looking to improve accuracy, Timney delivers a trigger that is innovative, dependable, and consistent, enhancing performance across a wide range of platforms. Timney's engineers have also eliminated the well-known trigger flop, resulting in the crisp, smooth break that defines a genuine Timney trigger.



This single-stage trigger features a factory-set, non-adjustable pull weight of 3 to 3.5 pounds and is designed to help you shoot with greater precision. It is available in either black or nickel-plated finishes and installs easily with no gunsmith required.

Each trigger is hand-assembled, carefully tested, and precisely calibrated, then backed by Timney's legendary lifetime warranty. Proudly made in the USA, it represents performance, reliability, and craftsmanship you can trust.

Attributes

- Name: [Marlin Lever Action Trigger for Model 336, 1894, and 1895 - 3-3.5lb Pull - Black - Straight](#)
- Manufacturer: [TIMNEY](#)
- Product no.: EU2016505
- Mfr. No.: Lever Gun-ST
- Model: 336
- Weapon type: Marlin
- Delivery weight: 1kg
- Shipping height: 51mm
- Shipping width: 102mm
- Shipping length: 191mm
- UPC: 081950538171

Table of Contents

- Startpage
- Safety Instruction Guide for Lever Action Triggers
- About Us

Safety Instruction Guide for Lever Action Triggers

Introduction

Thank you for choosing the Marlin Lever Action Trigger for Model 336, 1894, and 1895. This product is designed to enhance your shooting experience by providing a reliable and consistent trigger pull. However, it is essential to follow safety guidelines to ensure safe usage and optimal performance. This guide outlines important safety information, installation instructions, and disposal procedures to help you use this product responsibly.

General Safety Guidelines

- Always treat your firearm as if it is loaded, even if you believe it to be unloaded.
- Keep your finger off the trigger until you are ready to shoot.
- Always point the firearm in a safe direction.
- Ensure that you are in a safe environment when handling or using your firearm.
- Regularly inspect your firearm and trigger for any signs of damage or wear.
- Store your firearm and trigger in a secure location, out of reach of children and unauthorized users.
- Be aware of your surroundings and ensure that no one is in the line of fire when shooting.

Specific Safety Precautions for Use

- Ensure that the trigger is compatible with your specific firearm model (Marlin Model 336, 1894, or 1895).
- Do not attempt to adjust the pull weight of the trigger, as it is factoryset and nonadjustable.
- Avoid using the trigger in adverse weather conditions, such as heavy rain or extreme cold, which may affect performance.
- Do not use the trigger if you notice any malfunctions or irregularities.
- Always wear appropriate eye and ear protection when shooting.
- Be cautious when cleaning your firearm and trigger to avoid accidental discharge.

Instructions for Installation and Usage

1. Installation

- Ensure the firearm is unloaded and pointed in a safe direction.
- Remove the existing trigger according to your firearm's manual.
- Carefully install the Marlin Lever Action Trigger by following these steps:
 - Align the trigger with the designated slot in the firearm.
 - Secure the trigger in place according to the firearm's specifications.
 - Doublecheck that the trigger is properly installed and functions correctly before use.

2. Usage

- Familiarize yourself with the trigger's operation before using it in a live shooting scenario.
- Practice dry firing in a safe environment to get accustomed to the trigger's feel without live ammunition.
- When ready to shoot, load your firearm and ensure you are in a safe shooting position.
- Aim carefully and squeeze the trigger smoothly to ensure accuracy.

Disposal Instructions

- Dispose of the trigger responsibly in accordance with local regulations.
- Do not dispose of the trigger in regular household waste.
- Contact local authorities or waste management facilities for guidance on proper disposal methods.

Contact Information for Further Support

For safety inquiries or additional support regarding your Marlin Lever Action Trigger, please refer to the manufacturer's contact details provided with your product. It is essential to have access to assistance for any safetyrelated questions or concerns.

By following these safety guidelines and instructions, you can ensure a safe and enjoyable shooting experience with your Marlin Lever Action Trigger. Always prioritize safety and responsible firearm handling practices.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk