

# **Smith & Wesson Lever Action Triggers (Pull weight is not adjustable) - Smith & Wesson Lever Action Trigger for Model 1854 - 2.5-3lb Pull - Black - Straight**

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

If you want to enhance accuracy with your S and W® 1854 Series Rifle, Timney delivers a trigger designed just for that. Our engineers studied the rifle and developed a modern trigger tailored to the needs of lever-action shooters. Built for precision, reliability, and pure enjoyment, this trigger elevates the performance of any S and W® 1854 Series rifle.

S and W® 1854 Replacement Trigger Features:

- Factory-set pull weight: 2.5 – 3 lb
- Non-adjustable, single-stage design
- Improves shooting accuracy
- Black finish with a straight trigger shoe
- Easy drop-in installation, no gunsmith required
- Hand-assembled, tested, and calibrated
- Backed by Timney's legendary lifetime warranty

NO IMAGE  
AVAILABLE

## **Attributes**

- Name: [Smith & Wesson Lever Action Trigger for Model 1854 - 2.5-3lb Pull - Black - Straight](#)
- Manufacturer: [TIMNEY](#)
- Product no.: EU2016507
- Mfr. No.: Lever Gun S&W
- Delivery weight: 0.09kg
- Shipping height: 51mm
- Shipping width: 102mm
- Shipping length: 191mm
- UPC: 081950538799

# Table of Contents

- Startpage
- Smith & Wesson Lever Action Trigger Safety Instruction Guide
- About Us

# Smith & Wesson Lever Action Trigger Safety Instruction Guide

## Introduction

Thank you for choosing the Smith & Wesson Lever Action Trigger for Model 1854. This guide provides essential safety instructions to ensure the safe use and installation of your trigger. Please read this document carefully before use.

## General Safety Guidelines

- Always treat the firearm as if it is loaded.
- Ensure the firearm is pointed in a safe direction at all times.
- Store the trigger and firearm securely to prevent unauthorized access.
- Regularly inspect the trigger and firearm for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm ownership and usage.
- Use appropriate personal protective equipment (PPE) such as safety glasses when handling firearms.

## Specific Safety Precautions for Use

- Do not attempt to modify or adjust the pull weight of the trigger. It is factory set and nonadjustable.
- Ensure that the trigger is compatible with the Smith & Wesson® 1854 Series Rifle before installation.
- Only use the trigger with the specified model to avoid malfunctions or accidents.
- Keep fingers away from the trigger until ready to shoot.
- Be aware of your surroundings and ensure the shooting area is clear of people and obstacles.

## Instructions for Installation and Usage

### Installation

#### 1. Preparation

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools for installation (refer to your firearm's manual for specific tools required).

#### 2. Remove the Old Trigger

- Follow the manufacturer's instructions to safely disassemble the rifle.
- Carefully remove the existing trigger from the rifle.

#### 3. Install the New Trigger

- Align the Smith & Wesson Lever Action Trigger with the trigger housing.
- Insert the trigger and secure it according to the manufacturer's guidelines.
- Ensure the trigger operates smoothly without obstruction.

#### 4. Reassemble the Rifle

- Follow the disassembly instructions in reverse to reassemble the rifle.
- Doublecheck that all components are securely in place.

#### 5. Function Check

- Before using the firearm, conduct a function check to ensure the trigger operates correctly.
- Test the trigger in a safe environment, ensuring it functions as intended.

## Usage

- Always follow standard firearm safety protocols when using the rifle.
- Ensure you are familiar with the operation of the Smith & Wesson® 1854 Series Rifle before shooting.
- Regularly practice safe handling and shooting techniques.

## Disposal Instructions

- Dispose of the trigger in accordance with local regulations regarding electronic and mechanical waste.
- Do not dispose of the trigger in regular household waste.
- Contact local waste management authorities for proper disposal methods.

## Contact Information for Further Support

For any questions or concerns regarding the Smith & Wesson Lever Action Trigger, please refer to the manufacturer's website or customer service for assistance.

## Conclusion

Your safety is paramount when using the Smith & Wesson Lever Action Trigger. By following the guidelines provided in this instruction guide, you can ensure safe and effective use of your product. Always prioritize safety and responsible handling practices.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)