

MAUSER FEATHERWEIGHT (Pull weight adjustable 1.5-4lb) - MAUSER 98K FEATHERWEIGHT **3lb**

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

Hand honed and fitted for the ultimate in crisp, clean trigger pull. Adjusts for weight of pull (1 1/2 - 4 lb.), creep and overtravel. Lock nuts hold settings. Featherweight (FW) features the same adjustments and hand fitting as the Deluxe but no safety.



Attributes

- Name: [MAUSER 98K FEATHERWEIGHT **3lb**](#)
- Manufacturer: [TIMNEY](#)
- Product no.: EU2016613
- Mfr. No.: 202
- Delivery weight: 0.09kg
- Shipping height: 51mm
- Shipping width: 102mm
- Shipping length: 191mm
- UPC: 081950202003

Table of Contents

- Startpage
- MAUSER FEATHERWEIGHT Safety Instruction Guide
- About Us

MAUSER FEATHERWEIGHT Safety Instruction Guide

Introduction

Thank you for choosing the MAUSER FEATHERWEIGHT trigger. This guide provides important safety information and instructions to ensure the safe and effective use of your product. Please read this guide carefully before using the trigger.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Always handle firearms and their components with care, following all safety protocols.
- Keep the trigger and all firearm components out of reach of children and unauthorized users.
- Regularly inspect the trigger for any signs of wear or damage before use.
- If you notice any irregularities or malfunctions, cease use immediately and consult a qualified gunsmith.
- Report any unsafe products or accidents to the relevant authorities.

Specific Safety Precautions for Use

- Always ensure that the firearm is unloaded before installing or adjusting the trigger.
- Adjust the pull weight only when the firearm is in a safe and controlled environment.
- Do not exceed the maximum pull weight of 4 lb. to avoid unintended discharges.
- After adjustments, test the trigger in a safe environment to ensure proper functionality.
- Lock nuts must be securely fastened after adjustments to maintain settings.
- Use the trigger only with compatible firearms as specified by the manufacturer.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is completely unloaded.
- Remove the existing trigger according to the firearm's manual.
- Install the MAUSER FEATHERWEIGHT trigger by following the specific installation instructions provided in the firearm's manual.
- Secure all components and ensure they are properly fitted.

2. Adjusting the Pull Weight:

- Locate the adjustment screws on the trigger.
- Use a suitable tool to turn the screws clockwise to increase pull weight and counterclockwise to decrease pull weight.
- Adjust the pull weight within the range of 1.5 to 4 lb. according to your preference.
- After adjustments, tighten the lock nuts to secure the settings.

3. Testing:

- In a safe and controlled environment, test the trigger to ensure it functions correctly.
- Check for any creep or overtravel and adjust as necessary.

4. Regular Maintenance:

- Periodically check the trigger for any signs of wear or damage.

- Clean the trigger and surrounding areas as per the manufacturer's recommendations.

Disposal Instructions

- Dispose of the MAUSER FEATHERWEIGHT trigger according to local regulations for hazardous materials.
- Do not throw the trigger in regular household waste.
- Contact local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any safety inquiries or support regarding the MAUSER FEATHERWEIGHT trigger, please contact the manufacturer or your local authorized dealer. Ensure you have your product details ready for quicker assistance.

By following these guidelines, you can ensure the safe and effective use of your MAUSER FEATHERWEIGHT trigger. Thank you for prioritizing safety!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk