

MOSSBERG (Pull weight adjustable 1.5-4lb) - MOSSBERG, NICKEL PLATED **3lbW/Safety**

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

All Timney premium triggers are engineered for easy installation and improved accuracy. These true drop-in triggers require no gunsmith and install quickly and easily. Each trigger incorporates a Timney-designed trigger-blocking safety, ensuring the trigger will not move while the safety is engaged.



Features:

- Enhances accuracy and shooting consistency
- True drop-in design, no gunsmith required
- Trigger remains immobile when on safe
- Ready for the range out of the box or adjustable for a custom trigger feel

Attributes

- Name: [MOSSBERG, NICKEL PLATED **3lb**W/Safety](#)
- Manufacturer: [TIMNEY](#)
- Product no.: EU2016624
- Mfr. No.: 610-16
- Delivery weight: 0.09kg
- Shipping height: 51mm
- Shipping width: 102mm
- Shipping length: 191mm
- UPC: 081950610013

Table of Contents

- Startpage
- MOSSBERG Trigger Safety Instruction Guide
- About Us

MOSSBERG Trigger Safety Instruction Guide

Introduction

Thank you for choosing the MOSSBERG Pull Weight Adjustable Trigger. This guide provides essential safety instructions and information to ensure the safe and effective use of your product. Please read this guide carefully before installation and usage.

General Safety Guidelines

- Ensure that all safety guidelines are followed to prevent accidents and injuries.
- Always treat the trigger and firearm as if they are loaded.
- Keep firearms pointed in a safe direction at all times.
- Store your firearm and trigger in a secure location, away from children and unauthorized users.
- Regularly check for recalls and safety alerts via the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use the trigger only in accordance with the manufacturer's specifications.
- Ensure the firearm is unloaded before installing or adjusting the trigger.
- Avoid using the trigger if it appears damaged or malfunctioning.
- Always engage the safety mechanism when the firearm is not in use.
- Be aware of your surroundings and ensure a safe shooting environment.

Instructions for Installation and Usage

Installation

1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather all necessary tools for installation.

2. Remove the Existing Trigger:

- Follow the manufacturer's manual to safely remove the current trigger from your firearm.

3. Install the MOSSBERG Trigger:

- Carefully insert the MOSSBERG trigger into the trigger housing.
- Ensure it is seated properly and securely.

4. Adjust the Pull Weight:

- Use the adjustable feature to set the pull weight between 1.5 to 4 lbs as desired.
- Test the trigger to ensure it operates smoothly.

5. Final Check:

- Verify that the trigger is functioning correctly.
- Engage the triggerblocking safety to ensure safety during handling.

Usage

- Always follow safe shooting practices.

- Ensure that the safety is engaged when not actively shooting.
- Regularly check the trigger for any signs of wear or malfunction.

Disposal Instructions

- Dispose of the product in accordance with local regulations.
- Do not dispose of the trigger in regular household waste.
- Contact your local waste management authority for proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or product usage, please refer to the manufacturer's contact points provided with your product packaging or visit the official website.

Conclusion

By following these guidelines, you can ensure a safe and enjoyable experience with your MOSSBERG Pull Weight Adjustable Trigger. Always prioritize safety and remain informed about best practices and regulations. Thank you for your commitment to safety.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk