

RUGER TRIGGERS W/Tang Safety (Pull weight adjustable 1.5-4lb) - RUGER 77, NICKEL PLATED **3lb**

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

This trigger is factory calibrated and ready to shoot, while still offering full adjustability for sear engagement (creep) and pull weight, allowing you to tailor the trigger precisely to your shooting style.



Designed as a true drop-in upgrade, it installs easily with no gunsmith required and is ready for the range straight out of the box. The improved trigger geometry provides a clean, consistent break, helping shooters achieve greater accuracy and better shot control. Key features:

- Factory calibrated or fully adjustable for custom feel
- Adjustable sear engagement (creep) and pull weight
- Enhances accuracy and trigger consistency
- Easy installation, no gunsmith needed

Compatibility:

- Ruger® Mark 1 (Tang Safety)
- Built to Timney's exacting standards and individually tested, this trigger is a premium upgrade for Ruger Mark 1 owners who demand precision and reliability from their rifle.

Attributes

- Name: [RUGER 77, NICKEL PLATED **3lb**](#)
- Manufacturer: [TIMNEY](#)
- Product no.: EU2016629
- Mfr. No.: 601-16
- Delivery weight: 0.45kg
- Shipping height: 203mm
- Shipping width: 127mm
- Shipping length: 51mm
- UPC: 081950601011

Table of Contents

- Startpage
- RUGER TRIGGERS W/Tang Safety Safety Instruction Guide
- About Us

RUGER TRIGGERS W/Tang Safety Safety Instruction Guide

Introduction

Thank you for choosing the RUGER TRIGGERS W/Tang Safety. This product is designed to enhance your shooting experience with adjustable pull weight and sear engagement. To ensure your safety and the safety of others, please read and follow these instructions carefully.

General Safety Guidelines

- Always treat the trigger as if it is loaded.
- Keep your finger off the trigger until you are ready to shoot.
- Always point the firearm in a safe direction.
- Ensure that the firearm is safe and unloaded when installing or adjusting the trigger.
- Be aware of your surroundings and ensure that you have a safe backstop when shooting.
- Use appropriate eye and ear protection while shooting.
- Store the trigger and your firearm in a secure location, out of reach of children and unauthorized users.
- Report any unsafe products or incidents to the relevant authorities.

Specific Safety Precautions for Use

- Ensure that the trigger is compatible with your firearm model (Ruger® Mark 1 with Tang Safety).
- Adjust the pull weight only when the firearm is unloaded and pointed in a safe direction.
- Do not exceed the recommended pull weight range of 1.54lb.
- Regularly check the trigger for wear or damage before each use.
- If you experience any malfunction or if the trigger feels different, cease use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

Installation

1. **Unloading the Firearm:** Make sure your firearm is completely unloaded. Remove all ammunition and visually inspect the chamber.
2. **Disassembly:** Follow the manufacturer's instructions for disassembling your Ruger® Mark 1.
3. **Installing the Trigger:**
 - Remove the existing trigger and replace it with the RUGER TRIGGERS W/Tang Safety.
 - Ensure that the trigger is properly seated and aligned.
4. **Adjusting the Trigger:**
 - Use the adjustment mechanism to set the desired pull weight within the range of 1.54lb.
 - Adjust the sear engagement (creep) to your preference.
5. **Reassembly:** Follow the manufacturer's instructions to reassemble your firearm.
6. **Function Check:** Perform a function check to ensure that the trigger operates correctly before using the firearm.

Usage

- When ready to shoot, ensure that you are in a safe environment.
- Maintain a firm grip on the firearm and your finger off the trigger until you are ready to fire.
- After shooting, inspect the trigger and firearm for any signs of malfunction.

Disposal Instructions

- Dispose of the trigger and any associated packaging in accordance with local regulations.
- Do not dispose of the trigger in regular household waste. Check for local recycling programs or hazardous waste disposal sites.

Contact Information for Further Support

For safety inquiries or concerns about your RUGER TRIGGERS W/Tang Safety, please reach out to a qualified gunsmith or your local firearms dealer. Always ensure that you are receiving information from reputable sources.

By following these guidelines, you can help ensure a safe and enjoyable shooting experience. Thank you for prioritizing safety and responsible firearm use.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk