

# RUGER 1022 SILVER Trigger Complete Assembly (Pull weight 2 3/4lb NOT adjustable) - RUGER 1022 SILVER HOUSING, BLACK SHOE

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

The Timney 10/22® Trigger sets a new standard for aftermarket trigger upgrades for the Ruger® 10/22® platform. Designed as a complete action replacement, it features a one-piece housing CNC-machined from 6061-T6 aircraft-grade billet aluminum, delivering exceptional strength, precision, and reliability.



The trigger, sear, and hammer are wire-EDM cut from heat-treated steel to ensure outstanding durability and consistent engagement. Installation is fast and simple—remove the two factory action pins and drop in the complete Timney trigger assembly with no fitting required.

For enhanced usability, the trigger includes a Timney-designed extended magazine release that can be easily operated with a single finger, along with a standard auto bolt release. Like all Timney triggers manufactured in the USA, each assembly is hand-assembled, calibrated, and tested to provide a lifetime of dependable performance.

The trigger comes factory set at a crisp 2 lb pull weight with zero creep, delivering a clean, predictable break that significantly enhances accuracy and shooting confidence.

## Attributes

- Name: [RUGER 1022 SILVER HOUSING, BLACK SHOE](#)
- Manufacturer: [TIMNEY](#)
- Product no.: EU2016656
- Mfr. No.: 1022-1C-16
- Delivery weight: 0.23kg
- Shipping height: 32mm
- Shipping width: 108mm
- Shipping length: 171mm
- UPC: 081950102235

# Table of Contents

- Startpage
- RUGER 1022 SILVER Trigger Complete Assembly Safety Instruction Guide
- About Us

# RUGER 1022 SILVER Trigger Complete Assembly Safety Instruction Guide

## Introduction

Thank you for choosing the RUGER 1022 SILVER Trigger Complete Assembly. This guide provides important safety information and instructions to ensure the safe use and installation of your trigger assembly. Please read this guide thoroughly before use.

## General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep the firearm pointed in a safe direction at all times.
- Store firearms and ammunition separately and securely.
- Ensure that you are in a safe environment before handling your firearm.
- Keep your finger off the trigger until you are ready to shoot.
- Be aware of your target and what lies beyond it.
- Use appropriate protective gear, including eye and ear protection, when using firearms.
- Only use the trigger assembly with compatible Ruger 10/22 models.
- Regularly inspect your firearm and trigger assembly for any signs of wear or damage.

## Specific Safety Precautions for Use

- The trigger pull weight is factory set at 2 3/4 lbs and is not adjustable. Ensure you are comfortable with this pull weight before use.
- Do not modify the trigger assembly in any way, as this may compromise safety and performance.
- Ensure that the firearm is unloaded before installing or removing the trigger assembly.
- Always follow the manufacturer's instructions for installation and usage to prevent accidents.
- If you experience any issues with the trigger assembly, cease use immediately and consult a qualified gunsmith.

## Instructions for Installation and Usage

### Installation Steps

1. **Prepare Your Workspace:** Ensure you are in a clean, safe area free from distractions.
2. **Unload the Firearm:** Confirm that the firearm is completely unloaded. Remove the magazine and visually inspect the chamber.
3. **Remove Factory Action Pins:** Using a suitable tool, carefully remove the two factory action pins from the firearm.
4. **Insert the Timney Trigger Assembly:** Align the Timney trigger assembly with the action and gently drop it in place.
5. **Reinstall Action Pins:** Securely reinstall the factory action pins to hold the trigger assembly in place.
6. **Check Functionality:** Before using the firearm, check the trigger's functionality to ensure it operates correctly.

### Usage Instructions

- After installation, familiarize yourself with the trigger's operation before live firing.
- Always verify that the firearm is unloaded when not in use.
- Use the Timneydesigned extended magazine release for easy operation with one finger.
- Follow all standard safety practices when shooting.

## **Disposal Instructions**

When disposing of the trigger assembly or any firearm components, follow these guidelines:

- Do not dispose of the trigger assembly in regular household waste.
- Contact local authorities or a licensed dealer for proper disposal methods.
- Ensure that any disposed parts are rendered inoperable to prevent misuse.

## **Contact Information for Further Support**

For any questions or concerns regarding the RUGER 1022 SILVER Trigger Complete Assembly, please consult the manufacturer or a qualified gunsmith. Always ensure that you have the correct information before proceeding with modifications or usage.

## **Conclusion**

Your safety is our top priority. By following these guidelines and instructions, you can ensure a safe and enjoyable experience with your RUGER 1022 SILVER Trigger Complete Assembly. Always prioritize safety and responsible handling of firearms.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)