

RUGER 1022 SILVER Trigger Complete Assembly (Pull weight 2 3/4lb NOT adjustable) - RUGER 1022 SILVER HOUSING, RED SHOE

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

This trigger upgrade is designed to improve accuracy and overall rifle control while offering fast and effortless installation. The complete drop-in assembly installs easily with no gunsmithing required and is ready for the range straight out of the box, with no adjustments necessary.



Engineered for ease of use in the field, the trigger features an extended magazine release that can be operated comfortably with a single finger, ensuring excellent accessibility and control. Timney has set the benchmark for aftermarket upgrades for the Ruger 10/22® with this precision-built trigger assembly.

The trigger is factory set at a crisp 2.75 lb pull weight with zero creep, delivering a clean and consistent break. This model features a silver-colored housing paired with a red trigger shoe for a distinctive, high-quality finish.

Attributes

- Name: [RUGER 1022 SILVER HOUSING, RED SHOE](#)
- Manufacturer: [TIMNEY](#)
- Product no.: EU2016657
- Mfr. No.: 1022-2C-16
- Delivery weight: 0.23kg
- Shipping height: 32mm
- Shipping width: 108mm
- Shipping length: 171mm
- UPC: 081950102259

Table of Contents

- Startpage
- RUGER 1022 SILVER Trigger Complete Assembly Safety Instructions
- About Us

RUGER 1022 SILVER Trigger Complete Assembly Safety Instructions

Introduction

Thank you for choosing the RUGER 1022 SILVER Trigger Complete Assembly. This product is designed to enhance your shooting experience while ensuring safety and reliability. This guide provides essential safety instructions and guidelines to help you use this product safely and effectively.

General Safety Guidelines

- Always treat your firearm as if it is loaded.
- Keep your finger off the trigger until you are ready to shoot.
- Ensure that the firearm is pointed in a safe direction at all times.
- Store your firearm and ammunition separately and securely.
- Always wear appropriate eye and ear protection when shooting.
- Be aware of your surroundings and ensure that you have a safe backdrop when shooting.
- Follow all local laws and regulations regarding firearms.

Specific Safety Precautions for Use

- This trigger assembly is designed for use with the Ruger 10/22® rifle only. Do not attempt to use it with any other firearm.
- Ensure that the firearm is unloaded before installation or adjustments.
- Do not modify the trigger assembly or any component of your firearm beyond the manufacturer's specifications.
- Regularly inspect the trigger assembly for wear or damage. If you notice any issues, discontinue use and consult a qualified gunsmith.
- Ensure that the trigger pull weight is appropriate for your experience level. A pull weight of 2.75 lbs is factory set and should not be adjusted.
- Keep this product out of reach of children and unauthorized users.

Instructions for Installation and Usage

1. Preparation:

- Ensure that your Ruger 10/22® rifle is unloaded and pointed in a safe direction.
- Gather necessary tools for installation, including a screwdriver and any other required tools specified by the manufacturer.

2. Installation:

- Remove the existing trigger assembly from your Ruger 10/22® rifle by following the manufacturer's instructions.
- Carefully install the RUGER 1022 SILVER Trigger Complete Assembly into the rifle's housing.
- Ensure that all components are seated properly and securely.
- Reassemble the rifle according to the manufacturer's guidelines.

3. Testing:

- After installation, perform a function check to ensure that the trigger operates correctly.
- Verify that the trigger pull weight is consistent and that there is no creep.
- If any issues are detected, consult a qualified gunsmith before using the firearm.

4. Usage:

- When ready to shoot, ensure that you are in a safe location with appropriate safety measures in place.
- Always follow safe shooting practices, including maintaining a proper stance and grip on the rifle.

Disposal Instructions

- Dispose of the RUGER 1022 SILVER Trigger Complete Assembly in accordance with local regulations.
- Do not dispose of the product in regular household waste. Instead, use designated disposal facilities for firearms accessories.

Contact Information for Further Support

For any questions or additional information regarding safety, installation, or usage of the RUGER 1022 SILVER Trigger Complete Assembly, please refer to the manufacturer's website or customer support resources. It is important to have access to accurate and reliable information for your safety and the safety of others.

Conclusion

The RUGER 1022 SILVER Trigger Complete Assembly is a highquality upgrade designed to enhance your shooting experience. By following these safety guidelines and instructions, you can ensure safe and effective use of this product. Always prioritize safety and responsibility when handling firearms.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk