

# RUGER 1022 SILVER Trigger Complete Assembly (Pull weight 2 3/4lb NOT adjustable) - RUGER 1022 SILVER HOUSING, GOLD SHOE

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

This Timney trigger sets the benchmark for aftermarket trigger upgrades for the Ruger® 10/22® platform. Designed as a complete action replacement, it features a one-piece housing CNC-machined from 6061-T6 aircraft-grade billet aluminum for exceptional strength, precision, and durability.



The trigger, sear, and hammer are wire-EDM cut from heat-treated steel to ensure consistent engagement and long-term reliability. Installation is quick and simple—remove the two factory action pins and drop in the complete Timney trigger assembly with no fitting or gunsmithing required.

For enhanced usability, the trigger includes a Timney-designed extended magazine release that can be easily operated with a single finger, as well as a standard auto bolt release. Like all Timney triggers made in the USA, each assembly is hand-assembled, calibrated, and tested to deliver a lifetime of dependable performance.

The trigger comes factory set at a crisp 2.75 lb pull weight with zero creep, providing a clean, predictable break that enhances accuracy and control.

Category: Trigger assemblies

Compatibility: Ruger® 10/22®

## Attributes

- Name: [RUGER 1022 SILVER HOUSING, GOLD SHOE](#)
- Manufacturer: [TIMNEY](#)
- Product no.: EU2016659
- Mfr. No.: 1022-4C-16
- Weapon type: Ruger
- Delivery weight: 1kg
- Shipping height: 32mm
- Shipping width: 108mm
- Shipping length: 171mm
- UPC: 081950102297

# Table of Contents

- Startpage
- Safety Instruction Guide for RUGER 1022 SILVER Trigger Complete Assembly
- About Us

# Safety Instruction Guide for RUGER 1022 SILVER Trigger Complete Assembly

## Introduction

Thank you for choosing the RUGER 1022 SILVER Trigger Complete Assembly. This product is designed to enhance your shooting experience by providing a reliable and precise trigger mechanism for your Ruger® 10/22® platform. It is important to read and understand this safety instruction guide to ensure safe and effective use of the product.

## General Safety Guidelines

- Always treat the firearm as if it is loaded, even if you believe it to be unloaded.
- Keep your finger off the trigger until you are ready to shoot.
- Always point the firearm in a safe direction.
- Store firearms and ammunition separately and securely.
- Ensure that all parts of the firearm are in good working condition before use.
- Follow all local laws and regulations regarding firearm ownership and use.
- Be aware of your surroundings and ensure a safe environment for shooting.

## Specific Safety Precautions for Use

- This trigger assembly is designed for use with the Ruger® 10/22® platform only. Do not attempt to use it with any other firearm.
- Ensure that the firearm is unloaded before installation or handling of the trigger assembly.
- Avoid using the trigger assembly in wet or damp conditions to prevent rust and corrosion.
- Regularly inspect the trigger assembly for wear or damage. If any issues are found, discontinue use and consult a qualified gunsmith.
- Keep the trigger and surrounding areas clean and free from debris to ensure proper function.

## Instructions for Installation and Usage

### 1. Preparation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools: a punch tool for removing action pins.

### 2. Installation Steps:

- Remove the two factory action pins using the punch tool.
- Carefully lift the factory trigger assembly out of the firearm.
- Position the Timney trigger assembly into the action of the firearm.
- Reinsert the action pins to secure the new trigger assembly in place.

### 3. Testing:

- With the firearm pointed in a safe direction, perform a function check to ensure the trigger operates correctly.
- Ensure the pull weight is consistent at 2.75 lbs and that there is no creep.

### 4. Usage:

- Familiarize yourself with the new trigger feel before using it in a live shooting situation.

- Always maintain proper firearm safety practices while using the firearm.

## Disposal Instructions

- Dispose of the trigger assembly in accordance with local laws and regulations.
- Do not discard in regular household waste.
- If the trigger assembly is damaged or no longer functional, consider recycling the materials where applicable.

## Contact Information for Further Support

For any inquiries or concerns regarding the RUGER 1022 SILVER Trigger Complete Assembly, please reach out to the appropriate customer support channels provided by the manufacturer or retailer. Ensure to have your product details handy for efficient assistance.

By following these safety instructions, you can ensure a safe and enjoyable experience with your RUGER 1022 SILVER Trigger Complete Assembly. Always prioritize safety and responsible firearm handling.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)