

# **RUGER 1022 SILVER Trigger Complete Assembly (Pull weight 2 3/4lb NOT adjustable) - RUGER 1022 SILVER HOUSING, GREEN SHOE**

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

This Timney trigger sets the benchmark for aftermarket trigger upgrades for the Ruger® 10/22® platform. Designed as a complete action replacement, it features a one-piece housing CNC-machined from 6061-T6 aircraft-grade billet aluminum for exceptional strength, precision, and durability.

The trigger, sear, and hammer are wire-EDM cut from heat-treated steel to ensure consistent engagement and long-term reliability. Installation is quick and simple—remove the two factory action pins and drop in the complete Timney trigger assembly with no fitting or gunsmithing required.

For enhanced usability, the trigger includes a Timney-designed extended magazine release that can be easily operated with a single finger, as well as a standard auto bolt release. Like all Timney triggers made in the USA, each assembly is hand-assembled, calibrated, and tested to deliver a lifetime of dependable performance.

The trigger comes factory set at a crisp 2.75 lb pull weight with zero creep, providing a clean, predictable break that enhances accuracy and control.

Category: Trigger assemblies

Compatibility: Ruger® 10/22®

NO IMAGE  
AVAILABLE

## **Attributes**

- Name: [RUGER 1022 SILVER HOUSING, GREEN SHOE](#)
- Manufacturer: [TIMNEY](#)
- Product no.: EU2016660
- Mfr. No.: 1022-5C-16
- Delivery weight: 0.23kg
- Shipping height: 32mm
- Shipping width: 108mm
- Shipping length: 171mm
- UPC: 081950102310

# Table of Contents

- Startpage
- RUGER 1022 SILVER Trigger Complete Assembly Safety Instruction Guide
- About Us

# RUGER 1022 SILVER Trigger Complete Assembly Safety Instruction Guide

## Introduction

Thank you for choosing the RUGER 1022 SILVER Trigger Complete Assembly. This guide provides important safety instructions and guidelines to ensure the safe and effective use of your new trigger assembly. Please read this guide carefully before installation and use.

## General Safety Guidelines

- Ensure that the product is used only for its intended purpose as described in this guide.
- Always follow the manufacturer's instructions and safety recommendations.
- Keep the product out of reach of children and unauthorized users.
- Inspect the product regularly for signs of wear or damage. If any issues are found, discontinue use immediately.
- Report any unsafe products or accidents to the appropriate authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

## Specific Safety Precautions for Use

- Always handle firearms with care and treat every firearm as if it is loaded.
- Ensure that the firearm is unloaded before installation or maintenance.
- Do not attempt to modify or alter the trigger assembly in any way.
- Use only compatible firearms, specifically the Ruger® 10/22® platform.
- Wear appropriate safety gear, including eye and ear protection, when using firearms.
- Be aware of your surroundings and ensure a safe shooting environment.

## Instructions for Installation and Usage

### 1. Preparation:

- Ensure that the firearm is unloaded and pointed in a safe direction.
- Gather necessary tools: a punch tool to remove action pins.

### 2. Installation:

- Locate the two factory action pins on your Ruger® 10/22®.
- Use the punch tool to carefully remove the action pins.
- Once the pins are removed, gently lift the original trigger assembly out of the firearm.
- Take the Timney trigger assembly and drop it into the action without any fitting or gunsmithing required.
- Reinsert the two factory action pins to secure the trigger assembly in place.

### 3. Testing:

- Before using the firearm, conduct a safety check to ensure the trigger functions properly.
- Test the trigger pull weight to confirm it is set at 2.75 lb as intended.

### 4. Usage:

- When ready to shoot, ensure the firearm is pointed in a safe direction.
- Engage the safety mechanism (if available) until you are prepared to fire.

- Always follow safe shooting practices.

## **Disposal Instructions**

- Dispose of the trigger assembly in accordance with local regulations for electronic waste and metal recycling.
- Do not dispose of the product in regular household waste.

## **Contact Information for Further Support**

For any safety inquiries or concerns regarding the RUGER 1022 SILVER Trigger Complete Assembly, please refer to the manufacturer's contact information provided on the packaging or their official website.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)