

RUGER 1022 SILVER Trigger Complete Assembly (Pull weight 2 3/4lb NOT adjustable) - RUGER 1022 SILVER HOUSING, SILVER SHOE

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

This Timney trigger sets the benchmark for aftermarket trigger upgrades for the Ruger® 10/22® platform. Designed as a complete action replacement, it features a one-piece housing CNC-machined from 6061-T6 aircraft-grade billet aluminum for exceptional strength, precision, and durability.



The trigger, sear, and hammer are wire-EDM cut from heat-treated steel to ensure consistent engagement and long-term reliability. Installation is quick and simple—remove the two factory action pins and drop in the complete Timney trigger assembly with no fitting or gunsmithing required.

For enhanced usability, the trigger includes a Timney-designed extended magazine release that can be easily operated with a single finger, as well as a standard auto bolt release. Like all Timney triggers made in the USA, each assembly is hand-assembled, calibrated, and tested to deliver a lifetime of dependable performance.

The trigger comes factory set at a crisp 2.75 lb pull weight with zero creep, providing a clean, predictable break that enhances accuracy and control.

Category: Trigger assemblies

Compatibility: Ruger® 10/22®

Attributes

- Name: [RUGER 1022 SILVER HOUSING, SILVER SHOE](#)
- Manufacturer: [TIMNEY](#)
- Product no.: EU2016661
- Mfr. No.: 1022-6C-16
- Weapon type: Ruger
- Delivery weight: 1kg
- Shipping height: 32mm
- Shipping width: 108mm
- Shipping length: 171mm
- UPC: 081950102334

Table of Contents

- Startpage
- RUGER 1022 SILVER Trigger Complete Assembly Safety Instructions
- About Us

RUGER 1022 SILVER Trigger Complete Assembly Safety Instructions

Introduction

Thank you for choosing the RUGER 1022 SILVER Trigger Complete Assembly. This product is designed for the Ruger® 10/22® platform and aims to enhance your shooting experience. To ensure safe and effective use, please read this safety instruction guide thoroughly before installation and usage.

General Safety Guidelines

- Always handle firearms with care and follow all safety protocols.
- Ensure that the firearm is unloaded before beginning installation or maintenance.
- Keep the trigger assembly and all components out of reach of children and unauthorized users.
- Use the product only as intended and in accordance with these instructions.
- Regularly inspect the trigger assembly for wear and damage. Do not use if any parts are compromised.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Ensure you are familiar with the operation of the Ruger® 10/22® platform before installation.
- Avoid using the trigger assembly in any firearm other than the Ruger® 10/22®.
- Do not modify the trigger assembly in any way, as this may compromise safety and functionality.
- Always wear appropriate eye protection when handling firearms.
- Do not engage in any shooting activities while under the influence of drugs or alcohol.
- Be aware of your surroundings and ensure a safe shooting environment.

Instructions for Installation and Usage

1. Preparation:

- Ensure the firearm is completely unloaded.
- Gather necessary tools, including a punch tool for removing action pins.

2. Installation:

- Remove the two factory action pins from your Ruger® 10/22®.
- Carefully remove the factory trigger assembly from the firearm.
- Take the complete Timney trigger assembly and align it with the action of the firearm.
- Drop the Timney trigger assembly into place.
- Reinsert the two factory action pins to secure the assembly.

3. Testing:

- After installation, perform a function check to ensure the trigger operates correctly.
- Ensure the trigger pull weight is at the factory set 2.75 lb with no creep.
- Test the extended magazine release and auto bolt release for proper operation.

4. Usage:

- Follow all standard firearm handling and safety practices while using the Ruger® 10/22® with the installed trigger assembly.

- Regularly check the functionality of the trigger assembly and other firearm components.

Disposal Instructions

- Dispose of the trigger assembly and any associated packaging responsibly.
- Follow local regulations for the disposal of nonfood products.
- If the product is damaged or no longer usable, ensure it is disposed of in a manner that prevents unauthorized use.

Contact Information for Further Support

For any inquiries regarding safety, installation, or product performance, please refer to the manufacturer's contact details provided with the product packaging.

Thank you for your attention to these safety instructions. Your safety and enjoyment while using the RUGER 1022 SILVER Trigger Complete Assembly are our top priorities.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk