

SAKO TRIGGERS A ACTIONS - L461, L579 & L61 (Pull weight adjustable 1.5-4lb) - SAKO, BLACK **3lb** W/SAFETY

[Rifle Parts](#) > [Triggers Parts](#) > [Triggers](#)

These adjustable, featherweight-style, single-stage replacement triggers are designed for popular bolt-action rifles and deliver clean, crisp trigger pulls that enhance accuracy and shooting control. Precision-machined and hardened internal components ensure maximum reliability and long-term performance.



The trigger is fully adjustable for pull weight from 1.5 to 4 lbs, as well as for creep and overtravel, allowing shooters to fine-tune the trigger to their exact preferences. Locking nuts securely hold all adjustments in place for consistent settings under use.

The Sako Deluxe model is compatible with Sako "A" Series rifles, including the L461, L579, and L61.

Attributes

- Name: [SAKO, BLACK **3lb** W/SAFETY](#)
- Manufacturer: [TIMNEY](#)
- Product no.: EU2016662
- Mfr. No.: 621
- Delivery weight: 0.02kg
- Shipping height: 36mm
- Shipping width: 79mm
- Shipping length: 104mm
- UPC: 081950621002

Table of Contents

- Startpage
- SAKO TRIGGERS A ACTIONS L461, L579 & L61 Safety Instructions
- About Us

SAKO TRIGGERS A ACTIONS L461, L579 & L61 Safety Instructions

Introduction

Thank you for choosing the SAKO TRIGGERS A ACTIONS L461, L579 & L61. This product is designed to enhance your shooting experience with adjustable pull weights and precision performance. To ensure safe and effective use, please read and follow the safety instructions outlined in this guide.

General Safety Guidelines

- Always treat every firearm as if it is loaded.
- Keep firearms pointed in a safe direction at all times.
- Ensure the area is clear of people and obstacles before using the firearm.
- Store firearms and ammunition separately and securely to prevent unauthorized access.
- Regularly inspect your trigger and firearm for any signs of wear or damage.
- Follow all local laws and regulations regarding firearm ownership and use.

Specific Safety Precautions for Use

- Ensure that the trigger is properly installed and securely adjusted before use.
- Do not exceed the adjustable pull weight limits of 1.5 to 4 lbs.
- Be cautious of overtravel and creep adjustments; improper settings can lead to accidental discharges.
- Avoid using the trigger if you notice any irregularities or malfunctions.
- Always use appropriate protective gear, including eye and ear protection, when shooting.
- Keep fingers off the trigger until ready to shoot.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is unloaded and safe to handle.
- Remove the existing trigger according to the manufacturer's instructions.
- Install the SAKO trigger by following these steps:
 - Align the trigger with the mounting points on the firearm.
 - Securely fasten all screws and components according to the specifications.
 - Doublecheck that all connections are tight and secure.

2. Adjusting Pull Weight:

- Use the provided adjustment tool to modify the pull weight.
- Turn the adjustment screw clockwise to increase pull weight and counterclockwise to decrease it.
- Test the trigger pull after each adjustment to ensure it meets your preference.

3. Creep and Overtravel Adjustments:

- Adjust the creep setting to eliminate any unwanted movement before the trigger breaks.
- Set the overtravel to limit the distance the trigger moves after firing.
- Make small adjustments and test the trigger after each change.

4. Final Checks:

- Ensure all adjustments are secured with locking nuts to maintain consistency during use.

- Conduct a function test to verify that the trigger operates smoothly and safely.

Disposal Instructions

- Dispose of the product in accordance with local regulations for electronic and mechanical waste.
- Do not dispose of the product in regular household waste.
- Contact local waste management authorities for proper disposal methods.

Contact Information for Further Support

For any questions or concerns regarding the SAKO TRIGGERS A ACTIONS, please refer to the manufacturer's website or customer support resources.

Thank you for prioritizing safety and responsible usage of your SAKO TRIGGERS A ACTIONS L461, L579 & L61. Enjoy your shooting experience!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk