

Rings with Universal-Interface - Clamp Ring with Universal-Interface 34mm

Battle-Proven Modularity: Designed for installation on either the riflescope's main tube or objective bell, these clamping rings feature the field-proven ERATAC UNIVERSAL interface. This tactical system allows you to attach various Picatinny rail lengths and specialized adapter plates for mounting secondary optics or electronic accessories.



Optimized Split Configurations:

Main Tube Rings: Feature a dual-split (two-piece) design.

Objective Rings: Feature a single-split (one-piece) design.

Note: For riflescopes equipped with an integrated mounting rail on the main tube, only the objective-style rings can be used.

Streamlined and Adjustable Profiles: Each ring has a robust width of 18 mm and a low-profile base height (BH) of 3 mm. If additional clearance is required, the height can be easily increased using optional ERATAC spacer blocks.

Freely Indexable Positioning: When installing the rings onto your optic, the radial orientation can be rotated 360 degrees, allowing you to position your accessories at the exact angle that fits your shooting style.

Duty-Grade Build: CNC-machined from high-strength aluminum and finished with a non-reflective, matte black Mil-Spec Type III hardcoat anodization for maximum corrosion and wear resistance.

Attributes

- Name: Clamp Ring with Universal-Interface 34mm
- Manufacturer: ERATAC
- Product no.: EU2018009
- Mfr. No.: 03680-5734
- Colour: Black
- Delivery weight: 1kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- EAN/UPC: 03680-5734

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Rings with UniversalInterface Clamp](#)

Safety Instruction Guide for Rings with UniversalInterface Clamp

Introduction

Thank you for choosing the Rings with UniversalInterface Clamp. This product is designed to enhance your shooting experience by providing a reliable and adjustable mounting solution for your optics. Please read this safety instruction guide carefully to ensure safe and effective use of this product.

General Safety Guidelines

- **Product Safety:** Ensure safe use of the Rings with UniversalInterface Clamp by following all instructions provided in this guide.
- **Enhanced Recalls:** Stay informed about product recalls and safety notices. Regularly check for updates.
- **Online Shopping:** If purchased online, ensure that the retailer complies with the safety requirements as per EU regulations.
- **Special Consumer Focus:** This product is not intended for use by children. Keep out of reach of minors.
- **EU Contact Point:** For any safety inquiries, refer to the designated EU contact for this product.
- **Rapid Alerts:** Be aware of the Safety Gate system for updates on unsafe products.

Specific Safety Precautions for Use

- **Installation Precautions:**
 - Ensure that the mounting surface is clean and free from debris before installation.
 - Use only compatible accessories and attachments with the Rings with UniversalInterface Clamp.
- **Usage Precautions:**
 - Regularly check the integrity of the rings and connections before use.
 - Avoid overtightening screws as this may damage the rings or your optics.
 - Do not exceed the weight limit specified by the manufacturer for mounted accessories.
- **Environmental Precautions:**
 - Store the rings in a dry and cool environment to prevent corrosion.
 - Avoid exposing the rings to extreme temperatures or humidity.

Instructions for Installation and Usage

1. Installation:

- **Step 1:** Identify the mounting location on your riflescope (main tube or objective bell).
- **Step 2:** Align the clamping rings with the desired mounting position.
- **Step 3:** Use the appropriate tools to secure the rings onto the riflescope. Ensure they are tightened to the manufacturer's specifications.
- **Step 4:** If using spacer blocks for additional height, install them as per the instructions provided with the blocks.

2. Positioning:

- **Step 1:** Once installed, adjust the radial orientation of the rings to the desired angle.
- **Step 2:** Ensure that the positioning allows for comfortable access to any mounted accessories.

3. **Usage:**

- **Step 1:** After installation, verify that all components are securely fastened.
- **Step 2:** Use your riflescope as intended, monitoring for any signs of instability or misalignment during use.

Disposal Instructions

- Dispose of the Rings with UniversalInterface Clamp in accordance with local regulations for electronic waste and materials.
- Do not dispose of the product in household waste. Instead, use designated recycling facilities.

Contact Information for Further Support

For any inquiries or support regarding the Rings with UniversalInterface Clamp, please refer to the designated EU contact point associated with this product.

By following these safety instructions, you can ensure the optimal performance and longevity of your Rings with UniversalInterface Clamp while maintaining safety during use. Thank you for your attention to these guidelines.