

Rings with Universal-Interface - Clamp Ring with Universal-Interface 62mm

Battle-Proven Modularity: Designed for installation on either the riflescope's main tube or objective bell, these clamping rings feature the field-proven ERATAC UNIVERSAL interface. This tactical system allows you to attach various Picatinny rail lengths and specialized adapter plates for mounting secondary optics or electronic accessories.



Optimized Split Configurations:

Main Tube Rings: Feature a dual-split (two-piece) design.

Objective Rings: Feature a single-split (one-piece) design.

Note: For riflescopes equipped with an integrated mounting rail on the main tube, only the objective-style rings can be used.

Streamlined and Adjustable Profiles: Each ring has a robust width of 18 mm and a low-profile base height (BH) of 3 mm. If additional clearance is required, the height can be easily increased using optional ERATAC spacer blocks.

Freely Indexable Positioning: When installing the rings onto your optic, the radial orientation can be rotated 360 degrees, allowing you to position your accessories at the exact angle that fits your shooting style.

Duty-Grade Build: CNC-machined from high-strength aluminum and finished with a non-reflective, matte black Mil-Spec Type III hardcoat anodization for maximum corrosion and wear resistance.

Attributes

- Name: Clamp Ring with Universal-Interface 62mm
- Manufacturer: ERATAC
- Product no.: EU2018014
- Mfr. No.: 03680-5762
- Colour: Black
- Delivery weight: 0.08kg
- Shipping height: 100mm
- Shipping width: 100mm
- Shipping length: 100mm
- EAN/UPC: 03680-5762

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for Rings with UniversalInterface Clamp](#)

Safety Instruction Guide for Rings with UniversalInterface Clamp

Introduction

Thank you for choosing the Rings with UniversalInterface Clamp. This guide provides essential safety instructions to ensure the safe use and installation of your product. Please read this guide carefully before using the product to understand the safety precautions and proper handling.

General Safety Guidelines

- Ensure the product is used only for its intended purpose.
- Regularly inspect the product for any signs of wear or damage.
- Keep the product out of reach of children and vulnerable individuals.
- In case of any malfunction or damage, cease use immediately and consult a professional.
- Familiarize yourself with the product's features and limitations before use.
- Report any unsafe conditions or accidents to the appropriate authorities.

Specific Safety Precautions for Use

- **Hazard Awareness:** Be aware of potential hazards when using the rings, including:
 - Improper installation leading to equipment failure.
 - Loose components that may cause injury or damage.
- **Age Restrictions:** This product is not intended for children. Ensure that only individuals with adequate knowledge and skills handle the installation and use of the product.
- **Correct Usage:** Always follow the installation instructions carefully to avoid accidents.
- **Environmental Conditions:** Avoid using the product in extreme weather conditions that may affect its performance or integrity.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools before beginning installation.
- Ensure that the workspace is clean and free from distractions.

2. Installation Steps:

- Identify the main tube and objective bell of your riflescope.
- Choose the appropriate rings for installation based on your riflescope's design.
- For main tube rings, use the dualsplit design; for objective rings, use the singlesplit design.
- Position the rings on the riflescope and ensure they are aligned correctly.
- Tighten the clamping mechanism securely, but do not overtighten to avoid damaging the scope.
- If additional clearance is needed, use optional ERATAC spacer blocks to adjust the height.

3. Positioning:

- Rotate the rings to achieve the desired radial orientation (360 degrees) for optimal accessory placement.
- Ensure all accessories are securely attached and positioned for ease of use.

4. Final Check:

- After installation, doublecheck all components to ensure they are secure.
- Test the stability of the mounted accessories before use.

Disposal Instructions

- Dispose of the product in accordance with local waste management regulations.
- Ensure that any packaging materials are recycled or disposed of properly.
- If the product is damaged or no longer in use, do not leave it in accessible areas to prevent potential hazards.

Contact Information for Further Support

For any inquiries regarding safety, installation, or product support, please reach out to your local distributor or the manufacturer. It is important to have a point of contact for safetyrelated questions.

By following these guidelines, you can ensure a safe and effective experience with your Rings with UniversalInterface Clamp. Thank you for your attention to safety and proper usage.