

XL ULTRA"! MICROMETER SEATER DIES - FORSTER 408 CHEYTAC SEATER DIE

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Forster Reloading Dies are of excellent quality and provide the reloader with the ability to produce concentric rounds time and time again. Each die is manufactured from the finest quality steel carefully machined to very tight tolerances. Dies are hand polished both before and after the heat-treating process to guarantee an extra fine finish. All Forster reloading dies feature their Forster Cross Bolt Die Locking Ring that tightens the two ends of the split ring instead of tightening a screw directly into the threads of the die. The Forster Ultra Seater includes all of the features of the Forster Bench Rest Seater Die above, plus an ultra accurate micrometer adjustment. This micrometer adjustment allows you to adjust bullet seating depth from .0005 inch to .001 inch increments, and makes switching bullets easy - just dial back to your previous recorded setting. Forster Ultra Seaters make fine tuning your bullets to the lands of your rifling simple. These are XL dies that are 1-1/4" built for the XL Coax Press and large cartridges



Attributes

- Name: [FORSTER 408 CHEYTAC SEATER DIE](#)
- Manufacturer: [FORSTER](#)
- Product no.: 430107307
- Mfr. No.: 007525
- Cartridge: 408 CheyTac
- Die Style: Bullet Seating Die
- Delivery weight: 0.454kg
- Shipping height: 32mm
- Shipping width: 32mm
- Shipping length: 114mm
- UPC: 757253990076

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for XL ULTRA Micrometer Seater Dies
- About Us

Safety Instruction Guide for XL ULTRA Micrometer Seater Dies

Introduction

Thank you for choosing the XL ULTRA Micrometer Seater Dies, designed for the Forster 408 CheyTac Bullet Seater Die. This guide provides essential safety information and instructions to ensure safe and effective use of this product. Please read this guide carefully before using the product.

General Safety Guidelines

- Product Safety: Ensure safe use of the XL ULTRA Micrometer Seater Dies by following the guidelines provided. This product is designed for use with reloading equipment and should only be used as intended.
- Enhanced Recalls: Be aware that in the event of a product recall, standardized notices will be provided, and free remedies will be available for any dangerous products.
- Online Shopping: If purchased online, remember that you have the same safety protections as when buying from physical stores. Always ensure that the seller meets safety requirements.
- Special Consumer Focus: Extra safeguards should be taken if the product is used by vulnerable groups, such as children. Keep all reloading equipment out of reach of children.
- EU Contact Point: For safety inquiries, ensure that you have access to an EU-based contact for assistance.
- Rapid Alerts: Stay informed about updates on unsafe products through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including safety glasses and gloves, when handling reloading dies and associated equipment.
- Ensure that the workspace is clean, dry, and well-lit to prevent accidents.
- Keep the dies and all reloading components away from children and unauthorized users.
- Do not exceed the recommended specifications for bullet seating depth as indicated in the product specifications.
- Regularly inspect the dies for any signs of damage or wear. Do not use damaged dies.
- Follow the manufacturer's instructions for setup and operation closely to avoid misuse.

Instructions for Installation and Usage

1. Installation:

- Ensure that your reloading press is compatible with the XL ULTRA Micrometer Seater Dies before installation.
- Securely mount the die into the press according to the manufacturer's instructions.
- Adjust the Forster Cross Bolt Die Locking Ring to ensure the die is firmly in place.

2. Usage:

- Set the micrometer adjustment to your desired bullet seating depth. The adjustment can be made in increments of .0005 inch to .001 inch.
- Insert the bullet into the die and raise the ram of the press to seat the bullet to the specified depth.
- After seating, lower the ram and remove the completed cartridge.
- If switching to a different bullet, simply dial back to your previously recorded setting for quick adjustments.

3. Maintenance:

- Clean the dies regularly to prevent buildup of residue that can affect performance.
- Store the dies in a safe, dry location when not in use to prevent damage.

Disposal Instructions

- Dispose of any packaging materials in accordance with local regulations.
- If the dies are damaged beyond repair, follow local guidelines for the disposal of metal components. Do not dispose of in regular household waste.

Contact Information for Further Support

For any questions or concerns regarding the XL ULTRA Micrometer Seater Dies, please refer to the manufacturer's contact information provided with your product. Ensure that you have the model number and purchase details handy for efficient support.

By following these safety instructions, you can ensure a safe and effective reloading experience with your XL ULTRA Micrometer Seater Dies. Always prioritize safety and compliance with local regulations when using reloading equipment.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk