

# XL ULTRA"! MICROMETER SEATER DIES - FORSTER 50 BMG BULLET SEATER DIE

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

Forster Reloading Dies are of excellent quality and provide the reloader with the ability to produce concentric rounds time and time again. Each die is manufactured from the finest quality steel carefully machined to very tight tolerances. Dies are hand polished both before and after the heat-treating process to guarantee an extra fine finish. All Forster reloading dies feature their Forster Cross Bolt Die Locking Ring that tightens the two ends of the split ring instead of tightening a screw directly into the threads of the die. The Forster Ultra Seater includes all of the features of the Forster Bench Rest Seater Die above, plus an ultra accurate micrometer adjustment. This micrometer adjustment allows you to adjust bullet seating depth from .0005 inch to .001 inch increments, and makes switching bullets easy - just dial back to your previous recorded setting. Forster Ultra Seaters make fine tuning your bullets to the lands of your rifling simple. These are XL dies that are 1-1/4" built for the XL Coax Press and large cartridges



## Attributes

- Name: [FORSTER 50 BMG BULLET SEATER DIE](#)
- Manufacturer: [FORSTER](#)
- Product no.: 430107308
- Mfr. No.: 008000
- Cartridge: 50 BMG
- Die Style: Bullet Seating Die
- Delivery weight: 0.454kg
- Shipping height: 32mm
- Shipping width: 32mm
- Shipping length: 114mm
- UPC: 757253990069

## Item details

Made in USA

# Table of Contents

- Startpage
- Safety Instruction Guide for XL ULTRA! MICROMETER SEATER DIES FORSTER 50 BMG BULLET SEATER DIE
- About Us

# **Safety Instruction Guide for XL ULTRA! MICROMETER SEATER DIES FORSTER 50 BMG BULLET SEATER DIE**

## **Introduction**

Thank you for choosing the XL ULTRA! MICROMETER SEATER DIES FORSTER 50 BMG BULLET SEATER DIE. This product is designed for reloading ammunition safely and effectively. It is essential to follow the safety guidelines provided in this manual to ensure safe usage and optimal performance.

## **General Safety Guidelines**

- Always wear appropriate personal protective equipment (PPE) such as safety glasses and gloves when handling reloading dies.
- Keep the work area clean and organized to prevent accidents.
- Store all reloading components, including dies, in a secure location away from children and unauthorized users.
- Familiarize yourself with local laws and regulations regarding ammunition reloading and usage.
- Inspect the die and associated equipment for any damage before use. Do not use damaged equipment.
- Ensure that all tools and components are compatible with the XL ULTRA! MICROMETER SEATER DIES.

## **Specific Safety Precautions for Use**

- Ensure that the die is securely mounted in the press before starting the reloading process.
- Do not exceed the recommended bullet seating depth as specified in the die instructions.
- Be cautious when adjusting the micrometer settings; make small adjustments to avoid overshooting the desired depth.
- Keep fingers and other body parts clear of moving parts during operation.
- Use only the recommended type and caliber of bullets with this die to avoid malfunctions.
- Follow manufacturer instructions for cleaning and maintenance to ensure the die remains in safe working condition.

## **Instructions for Installation and Usage**

### **1. Installation:**

- Ensure the press is turned off and unplugged before installation.
- Securely mount the XL ULTRA! MICROMETER SEATER DIE in the press according to the manufacturer's instructions.
- Tighten the Forster Cross Bolt Die Locking Ring to ensure the die is stable during use.

### **2. Usage:**

- Prepare your reloading components and workspace.
- Set the micrometer adjustment to the desired bullet seating depth.
- Insert the bullet into the die and ensure it is properly aligned.
- Activate the press slowly while maintaining control of the bullet seating process.
- After seating, check the bullet depth with a caliper to ensure it meets specifications.
- If adjustments are needed, carefully dial the micrometer to the desired setting and repeat the seating process.

## Disposal Instructions

- Dispose of any unused or expired reloading components according to local regulations.
- Do not dispose of hazardous materials in regular trash. Check with local waste management for proper disposal methods.
- Ensure that all packaging materials are recycled or disposed of responsibly.

## Contact Information for Further Support

For any questions or concerns regarding the XL ULTRA! MICROMETER SEATER DIES FORSTER 50 BMG BULLET SEATER DIE, please refer to the manufacturer's website or contact their customer support for assistance.

## Conclusion

By following these safety instructions, you can ensure a safe and effective reloading experience with your XL ULTRA! MICROMETER SEATER DIES FORSTER 50 BMG BULLET SEATER DIE. Always prioritize safety and stay informed about best practices in ammunition reloading. Thank you for your attention and commitment to safety.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)