

FLAT WIRE RECOIL SPRINGS FOR GLOCK® - ISMI 13 LB. SPRING FOR GLOCK® 17

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Springs](#)

Designed For Maximum Consistency & Reliability

CAD designed and built to Aerospace specifications from chrome silicon, corrosion resistant, stainless steel or chrome vanadium for maximum durability, consistency and reliable performance. Built to aerospace specifications; heat treated, shot peened and fully stress relieved to minimize spring set. GLOCK® RECOIL SPRINGS - Flat wire, chrome vanadium alloy,, wound to fit factory diameter guide rod of .250" or less. GLOCK® 17 fits large frame 17,17L,20,21,22,24,31,35. Factory weight is 17 lb. GLOCK® 19 fits 19,23,25,32. Factory weight is 18 lb.



Attributes

- Name: [ISMI 13 LB. SPRING FOR GLOCK® 17](#)
- Manufacturer: [ISMI](#)
- Product no.: 445000012
- Mfr. No.: GL13
- Model: 17
- Pounds: 13 lbs
- Weapon type: Glock
- Delivery weight: 0.014kg
- Shipping height: 10mm
- Shipping width: 74mm
- Shipping length: 173mm

Item details

Made in USA

Table of Contents

- Startpage
- FLAT WIRE RECOIL SPRINGS FOR GLOCK® ISMI 13 LB. SPRING FOR GLOCK® 17 Safety Instructions
- About Us

FLAT WIRE RECOIL SPRINGS FOR GLOCK® ISMI 13 LB. SPRING FOR GLOCK® 17 Safety Instructions

Introduction

Thank you for choosing the FLAT WIRE RECOIL SPRING FOR GLOCK® ISMI 13 LB. SPRING FOR GLOCK® 17. This product is designed to enhance the performance of your Glock firearm. Please read this safety instruction guide carefully to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the recoil spring is compatible with your Glock model before installation.
- Always handle firearms with care and follow standard safety procedures.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the recoil spring for signs of wear or damage.
- If you experience any issues during installation or usage, seek professional assistance.

Specific Safety Precautions for Use

- Always ensure that your firearm is unloaded before installing or replacing the recoil spring.
- Do not attempt to modify the recoil spring or use it in any way other than intended.
- Avoid exposure to harsh chemicals or extreme temperatures that may affect the material integrity of the spring.
- Use appropriate personal protective equipment (PPE) when handling the recoil spring, such as gloves and safety glasses.
- Be aware of your surroundings and ensure you are in a safe environment when handling your firearm.

Instructions for Installation and Usage

1. Preparation

- Gather all necessary tools, including a punch tool and a vice or a stable work surface.
- Ensure that your Glock is unloaded and pointed in a safe direction.

2. Removal of the Old Recoil Spring

- Using the punch tool, carefully remove the guide rod from the slide.
- Take out the old recoil spring and discard it properly.

3. Installation of the New Recoil Spring

- Take the new FLAT WIRE RECOIL SPRING and align it with the guide rod.
- Ensure that the spring is wound correctly and fits snugly onto the guide rod.
- Insert the guide rod back into the slide, ensuring it is properly seated.

4. Final Checks

- Inspect the installation to ensure everything is secure.
- Perform a function check to ensure the firearm operates correctly.

5. Usage

- Use the firearm in accordance with the manufacturer's instructions and safety guidelines.
- Regularly check the recoil spring for wear and replace it as necessary.

Disposal Instructions

- Dispose of the old recoil spring and any packaging materials in accordance with local regulations.
- Ensure that all components are disposed of in an environmentally friendly manner.

Contact Information for Further Support

For any safety inquiries or further support, please refer to the manufacturer's contact information provided with your product. It is important to direct any questions or concerns regarding safety to the appropriate EUbased contact point.

Conclusion

Following these safety instructions will help ensure the safe and effective use of your FLAT WIRE RECOIL SPRING FOR GLOCK® ISMI 13 LB. SPRING FOR GLOCK® 17. Always prioritize safety and compliance with regulations to enjoy the full benefits of your product. Thank you for your attention to these important guidelines.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk