

1911 MAINSPRING - ISMI 19 LB. S/S SPRING, EACH

[Handgun Parts](#) > [Frame Parts](#) > [Mainspring Parts](#) > [Mainsprings](#)

Designed For Maximum Consistency & Reliability

CAD designed and built to Aerospace specifications from chrome silicon, corrosion resistant, stainless steel or chrome vanadium for maximum durability, consistency and reliable performance. Built to aerospace specifications; heat treated, shot peened and fully stress relieved to minimize spring set. 1911 AUTO MAINSPRING - Stainless steel (SS) or chrome silicon (CS); wound in the very popular 19 lb. and 17 lb. rate for lighter, consistent trigger pull with reliable ignition.



Attributes

- Name: [ISMI 19 LB. S/S SPRING, EACH](#)
- Manufacturer: [ISMI](#)
- Product no.: 445105191
- Mfr. No.: 19MS
- Model: Commander, Government
- Weapon type: 1911
- Delivery weight: 0.005kg
- Shipping height: 5mm
- Shipping width: 81mm
- Shipping length: 137mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for 1911 Mainspring ISMI 19 LB. S/S Spring
- About Us

Safety Instruction Guide for 1911 Mainspring ISMI 19 LB. S/S Spring

Introduction

Thank you for choosing the 1911 Mainspring ISMI 19 LB. S/S Spring. This product is designed for optimal performance and durability. To ensure safe usage and compliance with EU regulations, please read this safety instruction guide carefully before use.

General Safety Guidelines

- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and vulnerable individuals.
- Regularly inspect the product for any signs of wear or damage.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls by checking the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Handle the mainspring with care to avoid injury.
- Do not exceed the recommended weight specifications during use.
- Ensure that the mainspring is properly installed to prevent malfunction.
- Use appropriate tools and safety gear when installing or handling the mainspring.
- Avoid exposure to extreme temperatures and corrosive environments to maintain product integrity.

Instructions for Installation and Usage

1. Preparation:

- Gather all necessary tools and safety equipment.
- Ensure that you are working in a clean and welllit environment.

2. Installation:

- Follow the manufacturer's instructions for installing the mainspring.
- Ensure that the mainspring is seated correctly in the firearm.
- Doublecheck all connections and fittings for security.

3. Usage:

- Use the mainspring only in compatible firearm models (Government, Commander).
- Regularly check the performance of the mainspring to ensure reliable ignition.
- If you notice any irregularities in performance, discontinue use immediately and consult a professional.

Disposal Instructions

- Dispose of the mainspring in accordance with local regulations.
- Do not dispose of the product in regular household waste.
- Consider recycling options where available to minimize environmental impact.

Contact Information for Further Support

For further assistance, please consult the manufacturer or authorized dealer. Ensure that you have the product details available when seeking support.

By following these safety instructions, you can ensure a safe and effective experience with your 1911 Mainspring ISMI 19 LB. S/S Spring. Thank you for prioritizing safety and compliance with EU regulations.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk