

# TURBO SONIC ULTRASONIC CASE CLEANER - LYMAN TURBO SONIC 2500 CASE CLEANER 220V

[Reloading](#) > [Case Cleaning](#) > [Ultrasonic Case Cleaners](#)

Lyman's Turbo Sonic ultrasonic cleaner uses a combination of heated solution and ultrasonic frequency vibrations to break loose the toughest carbon and powder fouling in 10 minutes. Millions of small, fast-moving bubbles penetrate deep into the tiniest nooks and crannies, leaving heavily-fouled cases or gun parts clean as new. Features five, timed cleaning cycles from 3 minutes all the way up to 8 minutes for complete hands-off operation. Large 84 oz. (2.5 liter) stainless steel tank holds up to 240, 308 Winchester cases or 900, 9mm cases. 160 watt heating unit with built-in circuit protection and separate cooling fan prevents overheating. Specially formulated case cleaning solution handles the toughest fouling and powder residue and cleans brass, copper, bronze and stainless steel. Gun parts cleaning solution cleans steel, stainless steel and anodized aluminum. Models available that require 110 volt or 230 volt. Choose 230 volt for European use or 110 volt for Domestic US use.



## Attributes

- Name: [LYMAN TURBO SONIC 2500 CASE CLEANER 220V](#)
- Manufacturer: [LYMAN](#)
- Product no.: 749012599
- Mfr. No.: 7631702
- Delivery weight: 3.084kg
- Shipping height: 236mm
- Shipping width: 249mm
- Shipping length: 345mm
- UPC: 011516717023

# Table of Contents

- Startpage
- TURBO SONIC ULTRASONIC CASE CLEANER SAFETY INSTRUCTIONS
- About Us

# TURBO SONIC ULTRASONIC CASE CLEANER

## SAFETY INSTRUCTIONS

### Introduction

Thank you for choosing the Lyman Turbo Sonic Ultrasonic Case Cleaner. This product is designed to effectively clean your brass and gun parts using ultrasonic technology. To ensure safe and effective use, please read this safety instruction guide carefully.

### General Safety Guidelines

- Always follow the manufacturer's instructions and safety guidelines.
- Ensure the product is used for its intended purpose only.
- Keep the cleaner out of reach of children and vulnerable individuals.
- Regularly check for any signs of damage or wear on the unit before use.
- Do not use the cleaner if it is damaged or malfunctioning.
- Use only the recommended cleaning solutions to avoid chemical reactions.
- Ensure proper ventilation in the area where the cleaner is used.
- Do not immerse the cleaner's electrical components in water.
- Always unplug the unit when not in use or before cleaning.

### Specific Safety Precautions for Use

#### • Electrical Safety:

- Ensure the cleaner is connected to a power source that matches its voltage requirements (110V or 230V).
- Do not use extension cords or adapters that are not rated for the power requirements of the cleaner.
- Avoid using the cleaner in wet or damp conditions.

#### • Chemical Safety:

- Use the specially formulated case cleaning solution only as directed.
- Avoid skin contact with cleaning solutions. Wear gloves if necessary.
- In case of contact with skin or eyes, rinse immediately with plenty of water and seek medical advice.

#### • Operational Safety:

- Do not operate the cleaner while it is empty.
- Do not overload the tank beyond its maximum capacity.
- Keep the cleaner on a stable, flat surface during operation.
- Do not attempt to open the cleaner while it is in operation or during the heating cycle.

#### • Heat Safety:

- The heating unit can become hot during operation. Avoid direct contact with heated surfaces.
- Allow the unit to cool down completely before cleaning or storing.

### Instructions for Installation and Usage

#### 1. Installation:

- Place the cleaner on a stable, flat surface away from water and heat sources.
- Ensure the power switch is in the 'off' position before plugging in the unit.
- Select the appropriate voltage setting based on your region (110V for domestic use, 230V for European use).

## 2. Filling the Tank:

- Fill the stainless steel tank with water and the recommended cleaning solution up to the indicated fill line.
- Do not exceed the maximum fill line to prevent overflow during operation.

## 3. Operating the Cleaner:

- Turn on the power switch.
- Select the desired cleaning cycle (3 to 8 minutes) using the timer settings.
- Place the cases or gun parts into the tank, ensuring they are fully submerged.
- Close the lid securely during operation.

## 4. After Use:

- Once the cleaning cycle is complete, carefully open the lid.
- Allow the contents to cool before removing them from the tank.
- Dispose of used cleaning solution according to local regulations.

## Disposal Instructions

- Dispose of the cleaner and its components in accordance with local waste disposal regulations.
- Do not dispose of the cleaner in regular household waste.
- Check for recycling options available for electronic devices and cleaning solutions.

## Contact Information for Further Support

For any safety inquiries or concerns regarding the Lyman Turbo Sonic Ultrasonic Case Cleaner, please refer to the manufacturer's contact information provided on the product packaging or website.

By following these safety instructions, you can ensure a safe and effective cleaning experience with your Lyman Turbo Sonic Ultrasonic Case Cleaner. Always prioritize safety and stay informed about product recalls or safety alerts through the EU Safety Gate platform. Thank you for your attention to these important guidelines.

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)