

MEC LEAD CHARGE BARS FOR SINGLE STAGE PRESS - MEC RELOADING 1-3/4OZ SINGLE STAGE LEAD SHOT CHARGE BAR

[Reloading](#) > [Reloading Presses](#) > [Reloading Press Accessories](#)

The MEC Charge Bars allow you to adjust your shot charge and enable you to create the load you desire. Interchanges with the charge bar which is included with your reloading press. Available in both lead and steel styles for single stage and progressive presses.



Attributes

- Name: [MEC RELOADING 1-3/4OZ SINGLE STAGE LEAD SHOT CHARGE BAR](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019406
- Mfr. No.: 302134
- Size: 1-3/4 oz
- Delivery weight: 0.234kg
- Shipping height: 25mm
- Shipping width: 25mm
- Shipping length: 165mm
- UPC: 098489015554

Item details

Made in USA

Table of Contents

- Startpage
- MEC Lead Charge Bars Safety Instructions
- About Us

MEC Lead Charge Bars Safety Instructions

Introduction

Thank you for choosing the MEC Lead Charge Bars for your single stage reloading press. This guide provides essential safety instructions to ensure safe and effective use of the product. Please read this manual carefully before using the charge bars.

General Safety Guidelines

- Ensure that the MEC Lead Charge Bars are used only with compatible MEC reloading presses.
- Always wear appropriate safety gear, including safety glasses and gloves, while handling and using reloading equipment.
- Keep the work area clean and organized to prevent accidents and ensure safe handling of materials.
- Store the charge bars in a dry, secure location away from children and pets.
- Regularly inspect the charge bars for signs of wear or damage before each use.

Specific Safety Precautions for Use

- Do not exceed the recommended charge weight for your specific reloading press.
- Avoid using the charge bars if they are damaged or worn. Replace them immediately if you notice any issues.
- Always follow the manufacturer's instructions for loading and unloading shot into the charge bars.
- Use caution when adjusting the charge settings to prevent accidental spillage of materials.
- Ensure that the reloading press is securely mounted and stable before using the charge bars.

Instructions for Installation and Usage

1. Installation

- Ensure the reloading press is powered off and unplugged.
- Remove the existing charge bar from the press if applicable.
- Align the MEC Lead Charge Bar with the mounting slot on the press.
- Secure the charge bar in place according to the manufacturer's instructions.
- Doublecheck that the charge bar is firmly attached before proceeding.

2. Usage

- Measure the desired shot charge using the scale provided with your reloading press.
- Pour the shot into the charge bar, ensuring it is filled to the correct measurement.
- Operate the reloading press according to the manufacturer's guidelines, making sure to monitor the process closely.
- After use, clean the charge bar to remove any residue and maintain its condition.

Disposal Instructions

- Dispose of any damaged or worn charge bars according to local regulations.
- Do not discard charge bars in regular household waste. Check for any recycling programs available in your area.
- Ensure that all materials used in the reloading process are disposed of safely and responsibly.

Contact Information for Further Support

For any questions or concerns regarding the MEC Lead Charge Bars, please refer to the manufacturer's website or contact customer support. Be sure to have your product details and purchase information ready for assistance.

By following these safety instructions, you can ensure a safe and effective reloading experience with your MEC Lead Charge Bars. Always prioritize safety and adhere to the guidelines provided in this manual.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk