

# MEC SIZEMASTER SHELL PRESS - MEC RELOADING SIZEMASTER SINGLE STAGE RELOADING PRESS 16 GAUGE

[Reloading](#) > [Reloading Presses](#) > [Shotshell Presses](#)

The MEC Sizemaster is an all-in-one, single-stage reloader that offers simplicity and efficiency without sacrificing precision. Loaded with premium features like the E-Z Prime automatic primer feed and “Power Ring” collet resizer that returns every base to factory specifications. The new generation resizing station handles brass or steel heads, both high and low base. Adjustable for 3 shells, and available in 12, 20, 28 gauge and .410 bore (.410 not available with automatic primer feed). Includes 1 Charge Bar and 3 Powder Bushings.



## Attributes

- Name: [MEC RELOADING SIZEMASTER SINGLE STAGE RELOADING PRESS 16 GAUGE](#)
- Manufacturer: [MEC RELOADING](#)
- Product no.: 749019478
- Mfr. No.: 812016
- Gauge: 16 Gauge
- Delivery weight: 9.31kg
- Shipping height: 260mm
- Shipping width: 427mm
- Shipping length: 567mm
- UPC: 098489015325

## Item details

Made in USA

# Table of Contents

- Startpage
- MEC Sizemaster Shell Press Safety Instruction Guide
- About Us

# MEC Sizemaster Shell Press Safety Instruction Guide

## Introduction

Thank you for choosing the MEC Sizemaster Shell Press. This singlestage reloader is designed to provide simplicity and efficiency while ensuring precision in your reloading process. To ensure your safety and the safe operation of this product, please read and follow the safety instructions and guidelines outlined in this document.

## General Safety Guidelines

- Always read and understand the user manual before using the MEC Sizemaster Shell Press.
- Keep the workspace clean and free of obstructions to prevent accidents.
- Ensure that the press is used in a wellventilated area.
- Store all components and materials in a safe place, out of reach of children and pets.
- Wear appropriate personal protective equipment (PPE), such as safety glasses and gloves, when operating the press.
- Regularly inspect the press for any signs of wear or damage. Do not use if damaged.
- Follow all local laws and regulations regarding ammunition reloading.

## Specific Safety Precautions for Use

- **Hazard Identification:** Be aware that improper use of the reloader can lead to serious injuries, including but not limited to:
  - Eye injuries from flying debris
  - Burns from hot materials
  - Cuts from sharp components
- **Avoiding Hazards:**
  - Always ensure the press is in the correct position and secured before use.
  - Do not overload the press beyond its specified capacity.
  - Never attempt to reload ammunition in a distracted or hurried manner.
  - Keep hands and other body parts away from moving parts during operation.
  - Do not use the press with damaged or improperly fitted components.
- **Age Restrictions:** This product is intended for use by individuals aged 18 years and older. Ensure that minors are supervised if they are in the vicinity while the press is in use.

## Instructions for Installation and Usage

### 1. Installation:

- Choose a stable, flat surface for the installation of the MEC Sizemaster Shell Press.
- Secure the press to the work surface using appropriate mounting hardware to prevent movement during operation.
- Ensure that all components are properly assembled according to the user manual instructions.

### 2. Usage:

- Before starting, ensure that the area is clear of any obstructions and that you have all necessary materials at hand.
- Set the press for the desired gauge (16 Gauge for this model).

- Load the primer feed according to the instructions provided in the user manual.
- Follow the stepbystep reloading process as outlined in the manual, ensuring to adhere to safety precautions at each stage.
- After use, clean the press to remove any debris or residue.

## **Disposal Instructions**

- Dispose of any unused or expired components in accordance with local regulations.
- Do not dispose of reloading materials in regular household waste. Follow local guidelines for hazardous materials.
- If the MEC Sizemaster Shell Press is no longer in use, consider recycling or donating it if it is still in good condition.

## **Contact Information for Further Support**

For any safety inquiries or support regarding the MEC Sizemaster Shell Press, please refer to the official MEC website or your local MEC distributor for assistance.

## **Conclusion**

By following these safety guidelines and instructions, you can ensure a safe and effective reloading experience with the MEC Sizemaster Shell Press. Always prioritize safety and stay informed about best practices in ammunition reloading. Thank you for choosing MEC!

# About Us

## Brownells UK

### **Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories**

Unit 1, Laughing Dog Industrial Estate  
London Road  
Rugby  
Warwickshire  
CV23 9LP

[www.brownells.co.uk](http://www.brownells.co.uk)