

AR-15/M16 EXTRA-POWER HAMMER SPRING - HAMMER SPRING, 3-PAK

[Rifle Parts](#) > [Triggers Parts](#) > [Hammer Parts](#) > [Hammer Springs](#)

Helps Eliminate Common Ignition Problems Great When Using Ammo With Hard Primers

Durable, steel springs provide extra hammer power to ensure proper ignition with each trigger pull. Replaces factory spring. Note: For use in semi-auto models only. Not for use in full auto or burst fire models.



Attributes

- Name: [HAMMER SPRING, 3-PAK](#)
- Manufacturer: [WOLFF](#)
- Product no.: 969000101
- Mfr. No.: 30094
- Make: AR-15
- Delivery weight: 0.005kg
- Shipping height: 10mm
- Shipping width: 69mm
- Shipping length: 132mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for AR15/M16 ExtraPower Hammer Spring (3Pak)
- About Us

Safety Instruction Guide for AR15/M16 ExtraPower Hammer Spring (3Pak)

Introduction

Thank you for choosing the AR15/M16 ExtraPower Hammer Spring. This product is designed to enhance the hammer power of your firearm, ensuring reliable ignition with each trigger pull. Please read this safety instruction guide carefully to ensure safe usage and compliance with the EU General Product Safety Regulation (GPSR).

General Safety Guidelines

- Ensure that the product is used only in semiautomatic models. This product is not suitable for full auto or burst fire models.
- Always handle firearms responsibly and in accordance with local laws and regulations.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the hammer spring for wear or damage before use.
- Report any unsafe products or accidents to the relevant authorities.
- Stay informed about product recalls and safety alerts through the EU's Safety Gate platform.

Specific Safety Precautions for Use

- **Potential Hazards:** Improper installation or use of the hammer spring may lead to malfunction or accidental discharge.
- **Avoiding Hazards:**
 - Always ensure the firearm is unloaded before installing or handling the hammer spring.
 - Follow the manufacturer's instructions for installation and ensure all components are compatible with your firearm.
 - Use protective eyewear when working with firearm components.
 - Do not modify the hammer spring or use it in a manner not intended by the manufacturer.

Instructions for Installation and Usage

1. Preparation:

- Ensure your workspace is clean and free from distractions.
- Gather all necessary tools for installation, including a screwdriver and any other tools specified in your firearm's manual.

2. Installation:

- Unload the firearm completely and ensure it is pointed in a safe direction.
- Remove the factory hammer spring according to your firearm's manual.
- Carefully install the AR15/M16 ExtraPower Hammer Spring in the same position as the factory spring.
- Ensure that the spring is seated properly and securely in place.

3. Usage:

- After installation, conduct a function check to ensure the firearm operates correctly.
- Test the trigger pull in a safe and controlled environment.
- If you experience any issues, consult a qualified gunsmith for assistance.

Disposal Instructions

- Dispose of the hammer spring in accordance with local regulations regarding metal products.
- Do not dispose of the hammer spring in regular household waste.
- Consider recycling options available in your area.

Contact Information for Further Support

For any questions or concerns regarding the AR15/M16 ExtraPower Hammer Spring, please refer to the manufacturer's contact details provided on the product packaging or visit their official website.

Thank you for your attention to these safety guidelines. Your safety and the safety of others depend on responsible handling and usage of this product.

About Us

Brownells Austria

Brownells - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

www.brownells.at