

TYPE C EXTRA POWER SPRINGS FOR HARDBALL & HEAVIER LOADS - WOLFF 20 LB. RECOIL SPRING

[Handgun Parts](#) > [Recoil Parts](#) > [Recoil Springs](#)

Fine Tune For Light, Standard Or Heavy Loads

Like all Wolff springs, these for the 1911 Auto in .45, .38 Super or 9mm are the finest, most reliable, longest lasting ones available. The springs of choice for most of the nation's top builders. Except where noted, all recoil springs are supplied with an extra power firing pin spring that keeps the firing pin stop in place and prevents firing pin float ; an addition recommended by pistolsmith Bill Wilson. TYPE C - Extra Power For Hardball and Heavier Loads in Gov't./Gold Cup are for these guns in both .45 ACP and .38 Super. Allows more precise tuning of individual guns for better stripping, smoother cycling. Factory weight is 16 lb. Extra power firing pin spring included.



Attributes

- Name: [WOLFF 20 LB. RECOIL SPRING](#)
- Manufacturer: [WOLFF](#)
- Product no.: 969419200
- Mfr. No.: 41920
- Model: Government
- Pounds: 20 lbs
- Weapon type: 1911
- Delivery weight: 0.018kg
- Shipping height: 13mm
- Shipping width: 86mm
- Shipping length: 226mm

Item details

Made in USA

Table of Contents

- Startpage
- Safety Instruction Guide for TYPE C EXTRA POWER SPRINGS FOR HARDBALL & HEAVIER LOADS WOLFF 20 LB. RECOIL SPRING
- About Us

Safety Instruction Guide for TYPE C EXTRA POWER SPRINGS FOR HARDBALL & HEAVIER LOADS WOLFF 20 LB. RECOIL SPRING

Introduction

Thank you for choosing the TYPE C Extra Power Springs for Hardball & Heavier Loads from Wolff. This guide provides essential safety information and instructions to ensure the safe use of this product. Please read this guide carefully before use to ensure proper handling and maintenance.

General Safety Guidelines

- Ensure that all safety precautions are followed during installation and use.
- Always handle the recoil spring with care to avoid injury.
- Store the recoil spring in a cool, dry place away from direct sunlight and moisture.
- Regularly inspect the recoil spring for signs of wear or damage before each use.
- Follow all applicable laws and regulations regarding firearm accessories in your area.
- Keep this product out of reach of children and unauthorized users.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including eye protection, when handling firearms.
- Do not exceed the recommended weight specifications for the recoil spring.
- Ensure that your firearm is unloaded before installing or replacing the recoil spring.
- Follow the manufacturer's instructions for your specific firearm model to avoid potential hazards.
- Be aware of potential hazards such as pinching or snapping during installation.
- If you experience any malfunctions or unusual behavior after installation, discontinue use immediately and consult a qualified gunsmith.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is completely unloaded and the magazine is removed.
- Gather necessary tools, including a punch tool and a hammer.

2. Removing the Old Recoil Spring

- Carefully disassemble the firearm according to the manufacturer's instructions.
- Locate the recoil spring and gently remove it from its housing.
- Inspect the old spring for signs of wear or damage.

3. Installing the New Recoil Spring

- Take the TYPE C Extra Power Recoil Spring from its packaging.
- Insert the new recoil spring into the recoil spring housing, ensuring it is seated properly.
- Refer to the manufacturer's specifications for proper installation procedures.

4. Reassembling the Firearm

- Reassemble the firearm carefully, ensuring all parts are aligned and secure.
- Perform a function check to ensure the firearm operates correctly.

5. Testing

- Before using the firearm, conduct a test fire in a safe and controlled environment.
- Monitor the performance of the new recoil spring during use.

Disposal Instructions

- Dispose of the old recoil spring in accordance with local regulations.
- If the recoil spring is damaged or no longer usable, ensure it is disposed of in a manner that prevents accidental use.
- Consider recycling materials where applicable.

Contact Information for Further Support

For any safety inquiries or concerns regarding the TYPE C Extra Power Springs for Hardball & Heavier Loads, please refer to the manufacturer's contact information provided with the product packaging.

Conclusion

By following the guidelines and instructions outlined in this document, you can ensure the safe and effective use of the TYPE C Extra Power Springs. Always prioritize safety and compliance with local regulations when using firearm accessories. Thank you for your attention to this important safety information.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk