

Bench-Rest Neck Die 1 1/4 - Bench-Rest Neck Die 6,5x57

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

The BR-Seater is your reliable partner for highest precision in seating match bullets, or whenever in questions of "bullet runout", there is no room for compromise.

Thanks to the guide sleeve which is modelled like the cartridge chamber, the cartridge case will receive perfect axial guidance during the seating operation.

Also, the bullet will be guided in the same process.

This ensures perfect concentricity. Of course, the seater-head is replaceable. Various types of seater-heads are offered.

Choosing the correct seater head for the bullet used often improves concentricity significantly. You will find further instructions and assistance in selecting accessories and spare parts in the manual.

NO IMAGE
AVAILABLE

Attributes

- Name: [Bench-Rest Neck Die 6,5x57](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2013067
- Mfr. No.: 3154013
- Thread: 1 1/4
- Delivery weight: 0.65kg
- Shipping height: 55mm
- Shipping width: 55mm
- Shipping length: 155mm

Table of Contents

- Startpage
- Safety Instructions for BenchRest Neck Die 1 1/4 and BenchRest Neck Die 6.5x57
- About Us

Safety Instructions for BenchRest Neck Die 1 1/4 and BenchRest Neck Die 6.5x57

Introduction

Thank you for choosing the BenchRest Neck Die 1 1/4 and BenchRest Neck Die 6.5x57. This product is designed for precision reloading of cartridges. Please read this safety instruction guide carefully to ensure safe and effective use of the product.

General Safety Guidelines

- Always ensure that the product is used in accordance with the manufacturer's instructions.
- Keep the product out of reach of children and vulnerable individuals.
- Inspect the product for any damage before use. Do not use if damaged.
- Report any unsafe products or accidents to the appropriate authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Use the die only for its intended purpose of reloading ammunition.
- Ensure that the workspace is clean and free from obstructions before starting.
- Wear appropriate personal protective equipment, such as safety glasses, when using the die.
- Avoid wearing loose clothing or accessories that could become entangled during operation.
- Do not exceed the recommended specifications for the die to prevent accidents.
- Always follow the proper procedures for handling and storing ammunition components.

Instructions for Installation and Usage

1. Installation

- Ensure the reloading press is securely mounted on a stable surface.
- Insert the BenchRest Neck Die into the reloading press according to the manufacturer's instructions.
- Adjust the die to the desired height for proper cartridge resizing.

2. Usage

- Prepare the cartridge cases by cleaning and inspecting them for defects.
- Insert the cartridge case into the die, ensuring it is properly aligned.
- Slowly engage the press handle to resize the cartridge case.
- After resizing, remove the case from the die and inspect it for proper fit and alignment.
- If using different bullet types, switch to the appropriate seater head as needed.

Disposal Instructions

- Dispose of any damaged or unusable components according to local regulations.
- Recycle metal components when possible to minimize environmental impact.
- Do not dispose of ammunition or reloading components in regular household waste.

Contact Information for Further Support

For any inquiries or further assistance regarding the BenchRest Neck Die 1 1/4 and BenchRest Neck Die 6.5x57,

please refer to the manufacturer's contact information provided in the product manual.

Thank you for your attention to these safety instructions. Your safety is our priority.

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk