

Bench-Rest-Seater 1 1/4 - Bench-Rest-Seater 6,5x57

[Reloading](#) > [Reloading Dies](#) > [Rifle Dies](#)

The BR-Seater is your reliable partner for highest precision in seating match bullets, or whenever in questions of "bullet runout", there is no room for compromise.

Thanks to the guide sleeve which is modelled like the cartridge chamber, the cartridge case will receive perfect axial guidance during the seating operation.

Also, the bullet will be guided in the same process.

This ensures perfect concentricity. Of course, the seater-head is replaceable. Various types of seater-heads are offered.

Choosing the correct seater head for the bullet used often improves concentricity significantly. You will find further instructions and assistance in selecting accessories and spare parts in the manual.

NO IMAGE
AVAILABLE

Attributes

- Name: [Bench-Rest-Seater 6,5x57](#)
- Manufacturer: [TRIEBEL](#)
- Product no.: EU2013165
- Mfr. No.: 3154015
- Thread: 1 1/4
- Delivery weight: 0.85kg
- Shipping height: 55mm
- Shipping width: 55mm
- Shipping length: 155mm

Table of Contents

- Startpage
- BenchRestSeater Safety Instructions
- About Us

BenchRestSeater Safety Instructions

Introduction

Thank you for choosing the BenchRestSeater 1 1/4 and BenchRestSeater 6,5x57. This product is designed to provide the highest precision in seating match bullets and ensuring perfect concentricity. Please read this safety instruction guide carefully to ensure safe and effective use.

General Safety Guidelines

- Always use the BenchRestSeater in accordance with the manufacturer's instructions.
- Regularly inspect the product for any damage or wear before each use.
- Keep the product out of reach of children and unauthorized users.
- Use personal protective equipment (PPE) such as safety glasses when operating the seater.
- Ensure that the workspace is clean and free of obstructions to prevent accidents.
- Do not use the product for purposes other than intended.

Specific Safety Precautions for Use

- Ensure that the appropriate seater head is used for the bullet type to improve concentricity and avoid misalignment.
- Do not force the cartridge case into the guide sleeve; this may cause damage or injury.
- Always check that the seater head is securely attached before use.
- Avoid working with the seater in wet or damp conditions to prevent electrical hazards.
- If you experience any issues during operation, stop immediately and consult the manual for troubleshooting.

Instructions for Installation and Usage

1. Installation of the Seater Head

- Select the appropriate seater head for your bullet type.
- Ensure the seater head is clean and free from debris.
- Align the seater head with the seating mechanism and secure it in place.

2. Seating Operation

- Insert the cartridge case into the guide sleeve.
- Gently lower the seater head onto the bullet.
- Apply even pressure to seat the bullet into the cartridge case.
- Inspect the seated bullet for proper alignment and concentricity.

3. PostOperation Care

- Clean the seater and seater head after each use to prevent buildup of residue.
- Store the BenchRestSeater in a dry, cool place to avoid corrosion or damage.

Disposal Instructions

- Dispose of any damaged components in accordance with local regulations.
- Do not dispose of the product in household waste. Check for local recycling programs or hazardous waste disposal sites.

Contact Information for Further Support

For any inquiries or further assistance regarding safety, usage, or maintenance of the BenchRestSeater, please refer to the manufacturer's manual or website for detailed support.

Thank you for following these safety instructions. Your safety is our priority. Enjoy using your BenchRestSeater for precise bullet seating!

About Us

Brownells UK

Brownells UK - World's Largest Supplier of Gun Parts, Gunsmith Tools & Shooting Accessories

Unit 1, Laughing Dog Industrial Estate
London Road
Rugby
Warwickshire
CV23 9LP

www.brownells.co.uk